

RT-THREAD Documentation Center

Copyright @2019 Shanghai Ruiside Electronic Technology Co., Ltd.



Friday 28th September, 2018

Table of contents

e of	Contents	i
	1 Purpose and structure of this paper	1
	1.1 Purpose and background of this paper	1
	1.2 Structure of this paper	1
	2 Introduction to I2C device driver framework.	1
	3 Run the I2C device driver sample code	2
	3.1 Sample code hardware and software platform	2
	3.2 Enable I2C device driver	ļ
	3.3 Run the sample code	6
	4 Detailed explanation of I2C device driver interface.	,
	4.1 Find the device	8
	4.2 Data Transmission	9
	4.2.1. Sending Data	0
	4.2.2. Receiving Data	3
	4.3 I2C device driver application	6

This application note takes the 6-axis sensor MPU6050 driving the I2C interface as an example to explain how to use the I2C device driver interface to develop applications, and explains the RT-Thread I2C device driver framework and related functions in detail.

1 Purpose and structure of this paper

1.1 Purpose and Background of this Paper

The I2C (or i2c, IIC, iic) bus is a simple, bidirectional two-wire (clock

I2C is a synchronous serial bus (SCL, data SDA). It only needs two wires to transmit information between devices connected to the bus, and is
one of the most widely used communication interfaces for semiconductor chips. RT-Thread introduces the I2C device driver framework, which
provides two low-level hardware interfaces based on GPIO simulation and hardware controller.

1.2 Structure of this paper

This article first describes the basic situation of the RT-Thread I2C device driver framework, then describes the I2C device driver interface in detail, uses the I2C device driver interface to write the driver for the MPU6050, and gives a code example verified on the Zhengdian Atom STM32F4 Explorer development board.

2 Introduction to I2C Device Driver Framework

When using MCU for project development, the I2C bus is often needed. Generally speaking, MCU has an I2C controller (hardware I2C), or you can use the 2 GPIOs of the MCU to write your own program to simulate the I2C bus protocol to achieve the same function.

RT-Thread provides an I/O device management framework, which divides I/O devices into three layers for processing: application layer, I/O device management layer, and underlying driver. The I/O device management framework provides a unified device operation interface and I2C device driver interface to the upper layer application, and provides the underlying driver interface to the lower layer. The application accesses the underlying device through the standard interface provided by the I/O device module. Changes to the underlying device will not affect the upper layer application. This method makes the application very portable, and the application can be easily ported from one MCU to another.

This article takes the 6-axis inertial sensor MPU6050 as an example, uses the GPIO provided by the RT-Thread I2C device driver framework to simulate the I2C controller, and explains how the application uses the I2C device driver interface to access the I2C device.



1




Figure 1: RT-Thread I2C

Device driver framework

3Run the I2C device driver sample code

- 3.1 Sample Code Software and Hardware Platform
 - 1. Zhengdian Atom STM32F4 Explorer Development
 - Board 2. GY-521 MPU-6050 module
 - 3. MDK5
 - 4. RT-Thread source code
 - 5. I2C Example Code

The MCU of the Atom Explorer STM32F4 development board is STM32F407ZGT6. This example uses the USB serial port.

Port (USART1) sends data and supplies power, and uses SEGGER JLINK to connect to JTAG debugging.

The GY521 module used in this experiment is a 6-axis inertial sensor module with an onboard MPU6050. We use the PD6 (SCL) and PD7 (SDA) of the development board as analog I2C pins, and use Dupont wires to connect the SCL hardware of the GY521 module to PD6, SDA to PD7, GND to the GND of the development board, and VCC to 3.3V.




figure 2: Zhengdian Atom Development Board



-

This article is based on the Zhengdian Atom STM32F4 Explorer development board and gives the underlying I2C driver (GPIO simulation mode)

The adding method and specific application example code of I2C device (taking driving MPU6050 as an example), including register reading and writing



Due to the universality of the RT-Thread upper-layer application API, these codes are not limited to specific hardware platforms.

Platform, users can easily port it to other platforms.

3.2 Enable I2C device driver

- Use the env tool Enter the rt-thread\bsp\stm32f4xx-HAL directory in the command line and enter menuconfig
 Command to enter the configuration interface.
- Configure the shell to use serial port 1: Select Using UART1 and enter RT-Thread Kernel —> Kernel Device
 In the Object menu, change the device name for console to uart1.
- 3. Go to RT-Thread Components -> Device Drivers menu and select Using I2C device drivers.

This example uses GPIO to simulate I2C, so you also need to turn on Use GPIO to simulate I2C.




Figure 4: use menuconfig Open i2c

4. Exit the menuconfig configuration interface and save the configuration. Enter scons --target=mdk5 -s in the env command line.

The command generates a mdk5 project, and the new project is named project. Use MDK5 to open the project and modify the MCU model.

For STM32F407ZGTx, change the debug option to J-LINK.






Figure 5: Revise MCU




Figure 6: Modify debugging options

5. After compiling the project, download the program to the development board and run it. In the terminal PuTTY (open the corresponding port and configure the baud rate to

115200) Enter the list_device command to see the device named i2c2, the device type is I2C Bus,

It means that the I2C device driver has been added successfully. As shown in the figure



```
COM6-PuTTY

Thread Operating System

I Successful S
```

Figure 7: use list_device Command View i2c bus

3.3 Run the sample code

Copy main.c in the I2C sample code to the \rt-thread\bsp\stm32f4xx-HAL\applications directory

Record and replace the original main.c. Copy drv_mpu6050.c and drv_mpu6050.h to \rt-thread\bsp\stm32f4xx

-HAL\drivers directory, and add them to the corresponding groups in the project. As shown in the figure:




Figure 8: Adding Drivers

This example uses GPIO PD6 as SCL and GPIO PD7 as SDA. The I2C bus name is i2c2.

Modify the following parameters in drv_i2c.c as needed to adapt to your own board, and ensure that the parameters defined in drv_mpu6050.c

The macro MPU6050_I2C_BUS_NAME is the same as the macro I2C_BUS_NAME in $drv_i2c.c$.

To change the default driver port GPIOB of drv_i2c.c to GPIOD, as shown in the following figure:



```
D:\repository\rt-thread\bsp\stm32f4xx-HAL\drivers\drv_i2c.c - Notepad++
文件(F) 編輯(E) 搜素(S) 视图(V) 编码(N) 语言(L) 设置(T) 工具(O) 宏(M) 运行(R) 插件(P) 窗口(W) ?
] 🔒 🗎 🖫 🥫 😘 💪 | 🕹 🐚 🖍 | 🖎 🖎 | 🖎 C | ## 🦙 | 冬 🗢 | 🖫 🚰 | == 1 🖫 🖫 👺 💋 📨 💇 | 🖲 🕩 🗎 🗎 💥
🗎 drv_i2c. c🗵
 29
 30
      #include "drv_i2c.h"
 31
      #include <board.h>
 32
 33
      /*user can change this*/
 34
      #define I2C_BUS_NAME "i2c2"
 35
 36
      /*user should change this to adapt specific board*/
      #define I2C_SCL_PIN
#define I2C_SCL_PORT
                                            GPIO PIN 6
 37
 38
                                            GPIOD
      #define I2C_SCL_PORT_CLK_ENABLE
 39
                                             __HAL_RCC_GPIOD_CLK_ENABLE
                              GPIO_PIN_7
 40
      #define I2C SDA PIN
 41
      #define I2C_SDA_PORT
                              ····GPIOD
 42
      #define I2C_SDA_PORT_CLK_ENABLE
                                             __HAL_RCC_GPIOD_CLK_ENABLE
 43
```

Figure 9: dry i2c.c middle i2c Board Configuration

Connect the MPU6050 module and the development board, compile the project and download the program to the development board, reset the MCU, and then

PuTTY will print out the MPU6050 sensor data, which are temperature, three-axis acceleration, and three-axis angular velocity:

```
Putty
                                                                                          Thread Operating System
RT
          3.0.3 build Mar 9 2018
2006 - 2018 Copyright by rt-thread team
mpu6050 set i2c bus to i2c2
read mpu6050 id ok: 0x68
nsh >mpu6050: temperature=24
                                        gy=87
                               gx=4
                                                  gz=408
                                                           ax=3800 ay=76
                                                                                az=16684
                                    gy=40
mpu6050: temperature=24
                         gx=-1
                                             gz=-12 ax=3848
                                                                 ay=114
                                                                         az=16636
                                    gy=40
                                              gz=-11
mpu6050: temperature=24
                          gx=-1
                                                       ax = 3810
                                                                 ay=100
                                                                           az=16558
mpu6050: temperature=24
                          gx=-2
                                    gy=40
                                              gz=-11
                                                        ax = 3814
                                                                 ay=84
                                                                           az=16652
mpu6050: temperature=24
                          gx=-248
                                    gy=29
                                                       ax = 3398
                                                                 ay=330
                                                                           az=14516
                                              gz=-24
                                              gz=26
                          gx=16
                                    gy=80
mpu6050: temperature=24
                                                       ax = 4332
                                                                 ay=-8
                                                                           az=16522
                                              gz=-10
                                                                 ay=114
                                                                           az=16510
npu6050: temperature=24
                          gx=-1
                                    gy=42
                                                        ax = 4078
                                                                 ay=70
mpu6050: temperature=24
                                    gy=40
                                              gz=-10
                                                        ax=4066
                                                                           az=16548
                          gx=-1
```

Figure 10: Terminal print information

4 Detailed explanation of I2C device driver interface

Following the steps in the previous article, I believe that readers can quickly run the RT-ThreadI2C device driver.

How to develop applications using the I2C device driver interface?

The RT-Thread I2C device driver currently only supports host mode.

Use the menuconfig tool to enable the macros RT_USING_DEVICE and RT_USING_I2C if you want to use GPIO $\,$

To simulate I2C, you also need to enable the macro RT_USING_I2C_BITOPS.

The general process of using I2C device driver is as follows:

 Users can enter the list_device command in the msh shell to view the existing I2C devices and determine the I2C device name say.



- 2. Find the device using rt_i2c_bus_device_find() or rt_device_find(), pass in the I2C device name to get the I2C bus device handle.
- 3. Use rt_i2c_transfer() to send and receive data. If the host only sends data, you can use rt_i2c_master_send(). If the host only receives data, you can use rt_i2c_master_recv().

Next, this chapter will explain in detail the use of the I2C device driver interface.

4.1 Find Device

If an application wants to use an I2C device that has been managed by the operating system, it needs to call the device search function. Only after the I2C device is found can information be transmitted to the device.

Function prototype: struct rt_i2c_bus_device *rt_i2c_bus_device_find(const char * bus_name)

parameter describe

bus_name I2C Device Name

Function returns: If the I2C device exists, it returns the I2C device handle, otherwise it returns RT_NULL.

The source code for finding the device in mpu6050_hw_init() in the underlying driver drv_mpu6050.c in the sample code of this article is as follows:

```
#define MPU6050_12CBUS_NAME "i2c2" /* 12C device name, must be noted with drv_i2c.c

The registered I2C device name is consistent with */

static struct rt_i2c_bus_device *mpu6050_i2c_bus; /* 12C device handle*/
... ...

int mpu6050_hw_init(void) {

rt_uint8_t res;

mpu6050_i2c_bus = rt_i2c_bus_device_find(MPU6050_12CBUS_NAME); /* Find 12C device */

if (mpu6050_i2c_bus == RT_NULL) {

MPUDEBUG("can't find mpu6050 %s device\r\n",MPU6050_12CBUS_NAME); return

-RT_ERROR;
}

... ...
```



```
... ...
}
```

4.2 Data Transmission

The core API of RT-Thread I2C device driver is rt_i2c_transfer(), which transmits messages in chained form.

Through the message chain, multiple data transmission and reception can be completed by calling once. This function can be used to send data.

Can also be used to receive data.

Function prototype:

```
rt_size_t rt_i2c_transfer(struct rt_i2c_bus_device *bus,

struct rt_i2c_msg msgs[],

rt_uint32_t num)
```

parameter	describe
bus	I2C bus device handle
msgs[]	I2C message array
num	The number of messages in the array

Function returns: the number of successfully transmitted messages in the array

The message array msgs[] type is

addr slave address supports 7-bit and 10-bit binary addresses (flags |= RT_I2C_ADDR_10BIT).

The slave addresses used by the I2C device driver interface of RT-Thread are all addresses that do not contain read and write bits.

Change flags.

The optional flag value is a macro defined in the i2c.h file. The value of the sent data is RT_I2C_WR, and the value of the received data is

The value RT_I2C_RD can be combined with other macros using the bitwise operation "|" as needed.



```
#define RT_I2C_WR 0x0000

#define RT_I2C_RD (1u << 0)

#define RT_I2C_ADDR_10BIT (1u << 2) /* this is a ten bit chip address */

#define RT_I2C_NO_START (1u << 4)

#define RT_I2C_IGNORE_NACK (1u << 5)

#define RT_I2C_NO_READ_ACK (1u << 6) /* when I2C reading, we do not ACK

*/
```

4.2.1. Sending Data

Users can call the I2C device driver interface rt_i2c_master_send() or rt_i2c_transfer() to send

Data. The function call relationship is as follows:




Figure 11: Send data function call relationship

The mpu6050_write_reg() function in drv_mpu6050.c is used by the MCU to write data to the mpu6050 register. There are two implementations of this function, which call the I2C device driver interface rt_i2c_transfer() and rt_i2c_master_send() implementation.

The MPU6050 data sheet used in this example mentions that the 7-bit slave address is 110100X, where X is the chip's AD0.

The pin determines that the AD0 of the GY521 module is connected to GND, so the address of the MPU6050 as a slave is 1101000.

The hexadecimal format is 0x68. To write a register of MPU6050, the host first sends the slave address MPU6050_ADDR,

The read/write flag R/W is RT_I2C_WR (0 for write, 1 for read), and then the host sends the slave register address reg and datadata

1) Use rt_i2c_transfer() to send data

The underlying driver drv_mpu6050.c of the sample code in this article sends the data source code as follows:

```
#define MPU6050_ADDR 0X68

// Write mpu6050 single register
//reg: register address
```

```
//data: data //
return value: 0, normal / -1, error code rt_err_t
mpu6050_write_reg(rt_uint8_t reg, rt_uint8_t data) {
      struct rt_i2c_msg msgs;
      rt_uint8_t buf[2] = {reg, data};
      msgs.addr = MPU6050_ADDR;
                                                /* Slave address*//
      msgs.flags = RT_I2C_WR;
                                                * Write flag*/ /*
      msgs.buf = buf; msgs.len
                                                 Send data pointer*/
      = 2;
      if (rt_i2c_transfer(mpu6050_i2c_bus, &msgs, 1) == 1) {
           return RT_EOK;
      }
      else
      {
            return -RT_ERROR;
      }
}
```

Take the example of calling rt_i2c_transfer() to send data in the sample code of this article as an example. The hexadecimal value of the slave MPU6050 address is 0X68, the hexadecimal value of the register address reg is 0X6B, and the hexadecimal value of the data sent is 0X80. The sample waveform is shown in the figure below. The first data sent is 0XD0. The upper 7 bits of the first data are the slave address, and the lowest bit is the read/write bit (value is 0). Therefore, the first data is: 0X68 << 1|0 = 0XD0, and then the register address 0X6B and data 0X80 are sent in sequence.




Figure 12: /2C Sending data waveform example

2) Use rt_i2c_master_send() to send data

Function prototype:

```
rt_size_t rt_i2c_master_send(struct rt_i2c_bus_device *bus, rt_uint16_t addr,
```



```
rt_uint16_t flags,

const rt_uint8_t *buf,

rt_uint32_t count)
```

parameter	describe
bus	I2C bus device handle
addr	Slave address, excluding read/write bits
flags	Flag, read and write flag is write. Only 10-bit address selection is supported Select RT_I2C_ADDR_10BIT
buf	Pointer to the data to be sent
count	Number of bytes of data sent

Function returns: the number of data bytes successfully sent.

This function is a simple wrapper for rt_i2c_transfer() .

The underlying driver drv_mpu6050.c of the sample code in this article sends the data source code as follows:

```
0X68
#define MPU6050_ADDR
// Write mpu6050 single register
//reg: register address
//data: data
// Return value: 0, normal / -1, error code
rt_err_t mpu6050_write_reg(rt_uint8_t reg, rt_uint8_t data)
      rt_uint8_t buf[2];
      buf[0] = reg;
      buf[1] = data;
      if (rt_i2c_master_send(mpu6050_i2c_bus, MPU6050_ADDR, 0, buf ,2) ==
           2)
           return RT_EOK;
      }
      else
           return -RT_ERROR;
      }
```



4.2.2. Receiving Data

The user can call the I2C device driver interface rt_i2c_master_recv() or rt_i2c_transfer() to receive data. The function call relationship is as follows:




Figure 13: Receiving data function call relationship

The mpu6050_read_reg() function in the sample code drv_mpu6050.c in this article is used by the MCU to read data from the MPU6050 register. There are also two ways to implement this function, which respectively call the I2C device driver interface rt_i2c_transfer () and rt_i2c_master_recv().

To read a register of MPU6050, the host first sends the slave address MPU6050_ADDR, the read/write flag R/W is RT_I2C_WR (0 for write, 1 for read), and the slave register address reg before starting to read the device. Then send the slave address MPU6050_ADDR, the read/write flag R/W is RT_I2C_RD (0 for write, 1 for read), and save the read data pointer.

1) Use rt_i2c_transfer() to receive data

 $The \ underlying \ driver \ drv_mpu6050.c \ of \ the \ sample \ code \ in \ this \ article \ receives \ the \ data \ source \ code \ as \ follows:$

```
#define MPU6050_ADDR

0X68

// Read register data //reg:
register address to be read //len: number
of data bytes to be read //buf: storage
area for the read data // Return value: 0,
normal / -1, error code rt_err_t mpu6050_read_reg(rt_uint8_t
reg, rt_uint8_t len, rt_uint8_t *buf
)

{
    struct rt_i2c_msg msgs[2];

    msgs[0].addr = MPU6050_ADDR; msgs[0].flags /* Slave address */ /*
    = RT_12C_WR; Write flag */
```



```
/* Slave register address */
     msgs[0].buf = ® msgs[0].len
                                                    /* Number of bytes to send */
     = 1;
                                                    /* Slave address */
     msgs[1].addr = MPU6050_ADDR;
     msgs[1].flags = RT_I2C_RD;
                                                    /* Read flags */
                                                    /* Read data pointer */
     msgs[1].buf = buf; msgs[1].len
                                                    /* Number of bytes to read */
     = len;
     if (rt_i2c_transfer(mpu6050_i2c_bus, msgs, 2) == 2)
     {
           return RT_EOK;
     }
     else
     {
           return -RT_ERROR;
     }
}
```

Take the example of calling rt_i2c_transfer() to receive data in the sample code of this article as an example. The slave MPU6050 address is The hexadecimal value is 0X68, and the hexadecimal value of the register address reg is 0X75. The sample waveform is shown in the figure below. The data is 0XD0. The high 7 bits of the first data are the slave address, and the lowest bit is the read/write bit (the value is 0). A data value is: 0X68 <<10 = 0XD0, and then the register address 0X75 is sent.

The data is 0XD1, the read/write bit is read (value is 1), the value is: 0X68 << 1 | 1 = 0XD1, and then the read data is received 0X68.



Figure 14: I2C Sending data waveform example

2) Receive data using rt_i2c_master_recv()

Function prototype:



parameter	describe
bus	I2C bus device handle
addr	Slave address, excluding read/write bits
flags	Flag, read and write flag is read, only supports 10-bit address selection RT_I2C_ADDR_10BIT
buf	Accepts data pointer
count	Number of received data bytes

Function returns: the number of data bytes successfully received.

This function is a simple encapsulation of rt_i2c_transfer() and can only read data (receive data).

The underlying driver $drv_mpu6050.c$ of the sample code in this article receives the data source code as follows:

```
0X68
#define MPU6050_ADDR
// Read register data //
reg: register address to be read //len:
number of data bytes to be read //
buf: storage area for the read data //
Return value: 0, normal / -1, error code rt_err_t
mpu6050_read_reg(rt_uint8_t reg, rt_uint8_t len, rt_uint8_t *buf
     )
{
      if (rt_i2c_master_send(mpu6050_i2c_bus, MPU6050_ADDR, 0, &reg, 1) ==
           1)
      {
           if (rt_i2c_master_recv(mpu6050_i2c_bus, MPU6050_ADDR, 0, buf, len
                 ) == len)
           {
                 return RT_EOK;
           }
           else
           {
                 return -RT_ERROR;
           }
      }
      else
      {
           return -RT_ERROR;
```



```
}
```

4.3 I2C device driver application

Usually, the read-only registers of I2C interface chips are divided into two types: one is a single function register, and the other is a register with continuous addresses and similar functions. For example, the registers 0X3B, 0X3C, 0X3D, 0X3E, 0X3F,

0X40 stores the high 8 bits and low 8 bits of the three-axis acceleration X, Y, and Z axes in sequence.

The underlying driver drv_mpu6050.c in the sample code of this article uses the mpu6050_read_reg() function to read the 3-axis acceleration data of the MPU6050:

```
0X3B
#define MPU_ACCEL_XOUTH_REG
                                                           // Acceleration value, X-axis high 8-bit register
// Get acceleration value (raw
value) //gx,gy,gz: raw readings of gyroscope x,y,z axis (signed) //
Return value: 0, success / -1, error code rt_err_t
mpu6050_accelerometer_get(rt_int16_t *ax, rt_int16_t *ay,
     rt_int16_t *az)
{
      rt_uint8_t buf[6], ret;
      ret = mpu6050_read_reg(MPU_ACCEL_XOUTH_REG, 6, buf); if (ret == 0) {
            *ax = ((rt_uint16_t)buf[0] << 8) | buf[1]; *ay = ((rt_uint16_t)buf[2]
            << 8) | buf[3]; *az = ((rt_uint16_t)buf [4] << 8) | buf[5];
            return RT_EOK;
      }
      else
      {
            return -RT_ERROR;
      }
}
```

