Slat actuation power control unit

Interactive replacement process

Object code	DMC-MRDX-A-27-81-00-00A-258A-A	**Issue**	001-00 (new)
Issue date	2026-05-26	**Language**	en-GB
Responsible partner	AERALIS S.A.S. (U8025)	**Originator**	AERALIS S.A.S. — Technical Data Valmont (U8025)
Security	01 — Unclassified	**Quality assurance**	Unverified
Applicability	MRDX-42 and MRDX-46, all aircraft		

This process drives a technician through the replacement of a slat actuation power control unit on an electronic device. The printed form below gives the same sequence with the branches written out, for use when no device is available.

Process sequence

NODE 1 — ENTRY

1. Confirm the reason for the removal: scheduled replacement, fault message, or accomplishment of service bulletin MRDX-27-1042.

OUTCOME	NEXT
Fault message	Go to node 2
Scheduled or service bulletin	Go to node 3

NODE 2 — ISOLATE

1. Do the fault isolation procedure for the reported message before you remove the unit. A unit that is removed without fault isolation is charged to the operator if the shop finds no fault.

OUTCOME	NEXT
Fault confirmed on the unit	Go to node 3
Fault elsewhere	End of process

NODE 3 — REMOVE

1. Do the removal procedure. Record the serial number of the unit that is removed and the total flight hours of the aircraft.

OUTCOME	NEXT
Removal complete	Go to node 4

NODE 4 — INSTALL

1. Do the installation procedure with the replacement unit, then complete the post-installation check list.

OUTCOME	NEXT
All check list items signed	Go to node 5
An item cannot be signed	Go to node 4

NODE 5 — CLOSE

1. Close the aircraft, make the technical log entry and report the replacement through the customer services portal.

OUTCOME	NEXT
Complete	End of process