





Place acrylic feet under each of the 6 mounting holes. Make sure they do not overlap the edge of the board.

