









GND_1	GND	₁₀ <mark>32</mark> СН_СК
RESOUT 2	RESET	DD7 B3D7
5+ <u>3</u>	VCC	DDC 13400
	IRQ2	DDE DODO
5- <u>5</u>	-5V	DR/ 35U4
DRQ2 <u>6</u>	DRQ2	DDZ 37D3
12- <u>7</u>	-12V	DB2 38 D2
NC <u>8</u>	UNUSED	DB1 39D1
12+ 9	14.01/	DRO 40D0
GND_NC10	GND	IO DEADY 41 RDY1
MWR11	CMEMW	AFN 4ZAEN
MKU1Z	CMEMD	BA19 43A19
IUWRIS	TOW.	DA10 44A18
IORD14	IOD	DA47 45A17
DACK315	DACKZ	DAAC HOALD
DKW3 <u>16</u>	DDO3	BA15 47A15
DACK11/	DACK1	RA14 48 A14
DRQ118	DD04	BA13 49A13
REFRQ19	DACKO	BA12 DUALZ
CLK88 <u>20</u>	CLK	RA11 DIAII
IRQ/21	IDO7	BA10 52A10
IRQ622	IDOS	BA09 53A9
IRQ523	IDOE	D4A0
IRQ424	IDO/s	DAGT DOA/
IRQ325	IDOZ	DANG DOAG
DACK226	DVCKS	BANS D/AD
1027	TC	DAO/, DOA4
ALE 28	ALE	DAGZ DYAJ
5+ <u>29</u>		BA02 OUAZ
0SC88 <u>30</u>	030	BA01 DIAI
GND <u>31</u>	GND	BA00 62A0

