Defrost settings in Mild Conditions with higher humidity.

These settings will allow the defrost to kick in sooner than the defaults and run a little longer.

*These changes must be done in CELSIUS mode.

- 1. Unlock the controller (press the power button for 5 seconds)
- 2. Press the Function button (2nd from left) for 5 seconds until "00" appears at the bottom of the screen. (00 is the parameter number)
 - a. Raise the parameter number to 29
 - b. Press the Function button time and the value will begin to blink
 - c. Change the value from 45 minutes to 30 minutes
 - d. Press the function button one time to lock in the new value.
 - e. Raise the parameter number to 30
 - f. Press the Function button time and the value will begin to blink
 - g. Change the value from -7 to -5
 - h. Press the function button one time to lock in the new value.
 - i. Raise the parameter number to 31
 - j. Press the Function button time and the value will begin to blink
 - k. Change the value from -10 to -8
 - I. Press the function button one time to lock in the new value.
 - m. Raise the parameter number to 32
 - n. Press the Function button time and the value will begin to blink
 - o. Change the value from 10 to 8
 - p. Press the function button one time to lock in the new value.
 - q. Raise the parameter number to 33
 - r. Press the Function button time and the value will begin to blink
 - s. Change the value from 45 to 35
 - t. Press the function button one time to lock in the new value.
 - u. Raise the parameter number to 34
 - v. Press the Function button time and the value will begin to blink
 - w. Change the value from 8 to 10
 - x. Press the function button one time to lock in the new value.
- 3. Press the power button one time to exit parameter mode.

FORCE DEFROST SETTINGS

- 1. Unlock the controller by holding the power button down for 5 seconds...
- 2. Hold down the "DOWN + PROGRAM" Button (2nd from left) to force the defrost on. This only works if the unit is currently running and in heating mode.
- **3.** You can also safely use warm/hot water to assist in melting the current ice build up.