

Bato Bucket Hydroponic Setup

Complete Build Guide · Dragoon Mountains Edition

Dragoon Mountains, Cochise County, Arizona

Contents

1 • Equipment & Components	4
Tools & Additional Hardware	4
2 • Bench Construction & Assembly	7
Bench Frame	7
Downspout Installation	7
3 • Plumbing & Power	9
RAINPOINT Solar Pump Setup	9
Irrigation Cycle Settings	9
4 • Water Treatment — SE Arizona / Cochise County	11
Step 1 — Test Your Source Water	11
Step 2 — The Bicarbonate Problem	11
Water Source Quality — Ranked	12
pH Management — Local Cochise County Sources	12
5 • Nutrient Management — Masterblend Pepper Programme	15
Mixing Order — Always in This Sequence	15
Masterblend Pepper Programme — Per Gallon, by Growth Stage	16
Maximum EC Limits — Peppers	17
EC Drift Management	17
Nutrient Deficiency Quick Reference	17
6 • Irrigation Schedule	19
RAINPOINT Timer Programming	19
Reading Runoff	21
7 • Maintenance	22
Daily Checks	22
Weekly Tasks	22
End-of-Crop System Flush	22
8 • Materials & Rough Cost Breakdown	23
Bench & Infrastructure (One-Time)	23
Nutrients & Consumables (Per Season)	23
Where to Buy	24



Figure 1: *The Dragoon Mountains rising above the Sulphur Springs Valley, Cochise County, Arizona.*

A two-row bato bucket build — Cropking buckets on 2×4 lumber benches supported by 8×8×16 concrete blocks, RAINPOINT solar drip lines, and supplemental grow lighting. Poblano, jalapeño, and Chiltepin labeled on the buckets.

Key links: [CropKing Bato Buckets](#) · [RAINPOINT Solar Pump](#) · [Masterblend Bulk Kit](#) · [Masterblend 4-18-38 \(25 lb\)](#)

This guide is part of the Dragoon Mountains Growing Library:

- **Guide A — Growing Peppers in the Dragoon Mountains** · soil peppers, all varieties
- **Guide B — Bato Bucket Hydroponic Setup** (this guide) · complete pepper-system build
- **Guide C — Hydroponic Pepper Guide** · hydroponic pepper companion
- **Guide D — A Hydroponic Primer** · general-purpose hydroponic onramp
- **Guide E — High-Performance Hydroponic Growing** · LED / precision / indoor
- **Guide F — DIY Hydroponic Nutrients** · Masterblend from local materials
- **Guide G — DIY pH Down & pH Up** · foraged and homemade acid/base
- **Guide H — Growing Grapes in the Dragoon Mountains** · Cochise County viticulture

1 • Equipment & Components

Component	Specification
Cropking Bato Buckets	12"×10"×9" UV-resistant plastic with built-in drain port and two siphon elbows. Maintains a 2" nutrient reservoir at the bucket bottom between irrigation cycles. Cases of 10, free UPS shipping.
Drain channel	2×3 inch vinyl downspout with 2" holes drilled in the top face at each bucket position. Enclosed channel keeps drain solution dark, cool, and debris-free.
Reservoir	15-gal ACE Hardware black/yellow utility tub — fill to ~12 gal working volume. Keep lid on to block light and reduce evaporation.
Pump & timer	RAINPOINT solar automatic watering pump (B0DQ4DQL33) — solar-powered with built-in programmable timer. No wall outlet required. Minimum supported cycle interval is 8 hours.
Supply line	1/4" spaghetti tubing from RAINPOINT outlet to drip stakes at the base of each plant.
Growing medium	Coco coir / perlite blend (preferred). Coco provides moisture retention and cation exchange buffering; perlite ensures drainage and aeration. Both available at ACE Hardware or bulk from Amazon.
Nutrients	Masterblend 4-18-38 + bulk calcium nitrate (50 lb bags) + Epsom salt. 3-part system mixed directly into pre-treated reservoir water.

Tools & Additional Hardware



Figure 2: *The finished build — two rows of Cropping Bato buckets on lumber benches, hydroton-capped with perlite/coco beneath, RAINPOINT drip line and supplemental LED bar. Poblano, jalapeño, and Chiltepin labelled on the buckets.*

Tool	Purpose	Item	Purpose
Drill + 2" hole saw	Drain holes in downspout top face	1/4" barbed tee fittings	Branch supply at each bucket
Level	Verify bench slope	2×3 elbow + end cap	High end of drain channel — enclosed
Small wedge / shim	~1/4" elevation on uphill bench end	45° / 90° elbow	Low end — drain return into reservoir
Digital scale (0.1 g)	Accurate nutrient weighing	Mesh screen	Cover reservoir return — catches debris
pH meter	Check daily — target 5.8–6.2	Zip ties	Secure supply line to bench frame
EC/TDS meter	Monitor concentration daily	White vinegar	Monthly descale of pump & emitters

2 • Bench Construction & Assembly

Bench Frame

Item	Specification
Bench surface	Four 2×4×8 boards laid flat side by side. Provides a solid platform for the bato buckets and downspout channel with minimal flex.
Supports	Three 8×8×16 concrete building blocks at each end. Inexpensive, stable, no anchoring required on a patio surface.
Slope method	Place a ~1/4" wedge under the uphill end of the bench — almost any thin scrap works: wood shim, flat stone, plywood offcut. This minimal elevation creates sufficient gravity slope along the full 8-foot run.
Checking slope	Lay a level along the bench after shimming. The bubble should lean consistently toward the reservoir end. Adjust wedge before fixing the downspout.

Downspout Installation

1. **Mark hole positions** — With downspout flat on a work surface, mark hole centers on the top face at your chosen bucket spacing — 12" for peppers/herbs, 18-24" for tomatoes.
2. **Drill 2" holes — reverse technique** — Start in forward direction with just the pilot bit to lock center. Once hole saw teeth contact vinyl, switch drill to reverse. Reverse rotation scrapes rather than bites, producing a clean hole without cracking or binding. Back with a scrap 2×4 underneath.
3. **Deburr all holes** — Run a utility knife around each hole interior. Smooth edges prevent root debris from catching over the season.
4. **High end — elbow and cover** — At the uphill (high) end, install a 2×3 downspout elbow and cap it fully. This closes off the terminus so solution cannot back up or overflow out the high end, and keeps the channel completely enclosed — no light, insects, or debris.
5. **Low end — elbow to reservoir** — At the downhill end, fit a 45° or 90° elbow directing flow down into the 15-gal ACE tub. Keep the outlet below the waterline to

reduce splashing.

6. **Mount and place buckets** — Fix downspout on bench at confirmed slope. Set each Cropking bucket so the built-in drain port drops through its 2" hole. No fittings or sealant needed.
7. **Fill with coco/perlite** — Pre-wet coco and break up compressed blocks. Mix coco/perlite — 70/30 is a solid starting ratio. Fill each bucket to within 1-1.5" of the rim.

TIP: Drill all holes before mounting. Working flat on sawhorses is far easier than drilling in place on a sloped, fixed channel.

WARNING: Never use potting soil in bato buckets. It will clog the Cropking drain port within days. Coco/perlite or perlite-only media only.

3 • Plumbing & Power

RAINPOINT Solar Pump Setup

Item	Specification
Solar panel	Mount south-facing with 4-6+ hours of direct sun. In a high-desert SE Arizona location this is rarely a constraint. The adjustable bracket optimises angle by season.
Intake tube	Submerge in 15-gal reservoir — clip or weight below waterline, off the bottom to avoid drawing up settled minerals.
Outlet / supply line	1/4" tubing from RAINPOINT outlet along bench. Tee off at each bucket with barbed fittings; run spaghetti segment to drip stake at base of each plant.
No outlet needed	RAINPOINT handles pumping and scheduling in one unit. No separate submersible pump or cycle timer required.

Irrigation Cycle Settings

Parameter	Setting
Duration	10 minutes per cycle
Frequency	Every 8 hours — 3 cycles per day (6:00 AM / 2:00 PM / 10:00 PM)
Timer limitation	The RAINPOINT unit supports a minimum interval of 8 hours between cycles. Three cycles per day is the maximum frequency this timer supports. This cannot be reduced further.

Parameter	Setting
Hot month monitoring	During peak summer months (June–August) the 8-hour minimum interval may be insufficient on extreme heat days. Because cycle frequency cannot be increased beyond 3×/day with this timer, close monitoring of plants is required during these periods. Signs of stress between cycles — wilting, leaf curl — indicate the system is at its limit for that temperature range.
Transplant stage	Reduce to 5 min / 8 hr for week 1 — step back up to 10 min once roots show active growth.
Runoff target	10–20% of feed volume per cycle — a steady drip from the low-end drain elbow after each cycle.

TIMER NOTE: If hot-month wilting between cycles becomes a recurring problem, consider supplementing with a second pump and separate hose timer (available at ACE Hardware for ~\$15–20) that can be set to shorter intervals, running as a backup midday cycle during heat events.

4 • Water Treatment — SE Arizona / Cochise County

Water quality is the single most important factor in SE Arizona hydroponic growing. Cochise County well water is typically hard — high in dissolved calcium, magnesium, and especially bicarbonates that constantly push pH upward. Always treat your source water before adding any nutrients.

For step-by-step recipes for every acid and base listed in this section — prickly-pear vinegar, fermented citric acid, phosphoric-acid dilution, oak-ash lye — see the **DIY pH Down & pH Up guide (Guide G)**.

Step 1 — Test Your Source Water

Instrument	Purpose
EC/TDS meter	Measures dissolved minerals already in your water. SE AZ well water commonly reads 200–500 ppm before any nutrients are added.
pH meter	Target 5.8–6.2 for peppers. Local well water often reads 7.5–8.5.
Starting EC adjustment	If your source water EC is already 0.3 or higher, reduce your Masterblend dose proportionally. Plants cannot distinguish source minerals from added nutrients — excess causes toxicity.

Step 2 — The Bicarbonate Problem

Bicarbonates (HCO_3^-) are the main culprit in hard water pH instability. Even after you adjust pH down, bicarbonates act as a buffer and push it back up within hours. Neutralise them first, before adding any nutrients.

Step	Action	What Happens
1	Fill reservoir with source water	Starting pH likely 7.5–8.5
2	Add acid slowly while stirring (see pH section below)	Bicarbonates react — water fizzes as CO_2 releases
3	Wait for fizzing to stop completely	All bicarbonates are neutralised

Step	Action	What Happens
4	Adjust pH down to 5.8-6.0	Now pH is stable — won't bounce back quickly
5	Add nutrients in the correct order (see Section 5)	Nutrients dissolve into pre-treated, stable water

Water Source Quality — Ranked

Source	Baseline EC	Baseline pH	Treatment Needed	Rating
Monsoon rainwater (collected)	< 20 ppm	6.0-6.5	Minimal — just pH fine-tune	Best
RO filtered water	< 50 ppm	6.5-7.0	Light pH adjustment	Excellent
RO / rain 50:50 blend	0.1-0.2	6.5-7.0	Light pH adjustment	Very Good
Treated well water	0.3-0.8	After treatment	Reduce nutrient dose to account for base minerals	Usable
Untreated well water	0.3-0.8	7.5-8.5	Full bicarbonate scrub + pH down — do not skip	Difficult

pH Management — Local Cochise County Sources

pH Down Options

Source	Method	Strength	Notes
Prickly pear vinegar	Ferment crushed prickly pear juice open to air 2-4 weeks	pH 3-4	Best local option — unlimited supply. Gentle, easy to dose. Keep a small spray bottle for daily micro-adjustments.
Food-grade citric acid	Dissolve powder in water to make stock solution	Precise	Best purchased option — very accurate dosing. Standard use for bicarbonate pre-treatment.
Phosphoric acid (pH Down)	Commercial — dilute stock solution	Very strong	Most reliable for hard well water pre-treatment.
Sulfur burn	Burn local sulfur, bubble gas through water outdoors	pH 1-2	Strong — do outdoors only. Fumes are irritating. Not recommended for routine use.

pH Up Options

Source	Method	Strength	Notes
Oak ash lye	Pack ash in container, pour rainwater through, collect dark liquid	pH 11-13	Also adds potassium. Dilute heavily before use. Best local option.
Potassium hydroxide (pH Up)	Commercial — dilute stock solution	Strong	Most reliable and precise. Standard commercial choice.

Source	Method	Strength	Notes
Baking soda	Dissolve in water	Gentle	Easy to dose but sodium accumulates in reservoir over time — use sparingly.

MONSOON TIP: July–September monsoon rainwater is your best possible source water — < 20 ppm, near-neutral pH. Set up even a simple roof catchment system. A 500 sq ft covered patio collects 3,000+ gallons per monsoon season. Store in dark, covered tanks. Using monsoon water eliminates the bicarbonate problem entirely for the second half of the season.

5 • Nutrient Management — Masterblend Pepper Programme

Peppers are heavy feeders with evolving nutrient needs. The Masterblend 3-part system delivers everything peppers need — the key is adjusting concentration (not ratio) as the plant moves through its stages. **Peppers are the heaviest magnesium users of common hydroponic crops — once fruit sizing begins, the Epsom salt dose increases significantly.**

Want to replace any of these three Masterblend components with locally-foraged Cochise County materials? See the **DIY Hydroponic Nutrients guide (Guide F)** for oak-ash potassium, bat-guano nitrogen, caliche calcium, and Sulphur Springs Valley epsomite recipes.

Mixing Order — Always in This Sequence

CRITICAL: Calcium nitrate must always be added **LAST**. Adding it before Masterblend is fully dissolved — or mixing the two as dry concentrates — causes immediate calcium-sulfate precipitation and nutrient lockout. Always dissolve each component separately in the reservoir.

Step	Component	Amount	12-gal reservoir	Notes
1	Masterblend 4-18-38	2.4 g / gal	28.8 g	Add first — dissolve fully before adding anything else
2	Epsom salt (MgSO ₄)	1.2 g/gal (baseline) · 2.4 g/gal fruiting ★	14.4 g · 28.8 g fruiting	Add second. Double dose once fruit sizing begins — peppers need significantly more Mg than other crops.

Step	Component	Amount	12-gal reservoir	Notes
3	Calcium nitrate (15.5-0-0)	2.4 g / gal	28.8 g	Add LAST — always. Dissolve separately. Never combine with Masterblend in concentrated form.

Masterblend Pepper Programme — Per Gallon, by Growth Stage

Adjust concentration as the plant progresses — the ratio stays the same but the dose changes. Note the Epsom salt increase at fruit sizing.

Stage	Masterblend (g/gal)	Epsom Salt (g/gal)	Cal-Nitrate (g/gal)	Target EC (mS/cm)	pH
Seedling / cutting	1.2	0.6	1.2	0.8 - 1.0	5.8 - 6.0
Early vegetative	2.4	1.2	2.4	1.4 - 1.8	5.8 - 6.0
Late vegetative	2.8	1.4	2.8	1.8 - 2.2	5.8 - 6.2
First flower buds	2.8	1.4	2.8	1.8 - 2.2	5.8 - 6.2
Peak flowering	2.4	1.2	2.4	1.6 - 2.0	5.8 - 6.0
Fruit sizing ★ Mg up	3.0	2.4 ★	3.0	2.0 - 2.6	6.0 - 6.2
Peak fruiting	3.0	2.4	3.0	2.2 - 2.8	6.0 - 6.2
Late harvest	2.0	1.0	2.0	1.4 - 2.0	6.0

★ **PEPPER Mg RULE:** Peppers are the heaviest magnesium users of all common hydroponic crops. Once fruit sizing begins, increase Epsom salt to 2.4 g/gal — double the

standard Masterblend ratio. Magnesium deficiency (yellowing between green veins on older leaves) is the single most common pepper deficiency in hydroponics and is easily prevented by this increase.

Maximum EC Limits — Peppers

Limit	Value
Maximum EC	3.2 mS/cm — above this, salt stress causes tip burn, blossom drop, and stunted fruit
Flowering EC	Keep EC at 1.8-2.2 through peak flowering — EC above 3.0 during bloom causes osmotic stress and flower drop
Blossom end rot	Almost always a pH or EC problem in hydroponics, not a calcium deficiency — check pH and EC first before adjusting calcium

EC Drift Management

Condition	Response
EC rising between top-offs	Plants drinking more water than nutrients — top off with plain RO or rain water until EC returns to target
EC falling between top-offs	Plants consuming nutrients heavily — top off with half-strength Masterblend mix
pH rising daily despite adjustment	Bicarbonate effect from source water — pre-treat next reservoir fill with citric acid or phosphoric acid before adding any nutrients
Full reservoir change	Every 7-10 days during fruiting, every 14 days during vegetative growth. Flush system with clean water between changes to prevent salt buildup.

Nutrient Deficiency Quick Reference

Symptom	Deficiency	Hydroponic Fix	pH Cause
Yellow between green veins — older leaves first	Magnesium (Mg)	Double Epsom salt to 2.4 g/gal for 2 weeks. Foliar spray 1 tbsp/gal as fast response.	Locked out below 5.5
Yellow between green veins — new growth first	Iron (Fe) or Mn	Check pH immediately — almost always pH > 6.5. Adjust to 5.8-6.0.	Locked out above 6.5
Dark spot on fruit base	Calcium (Ca) — blossom end rot	Check pH is 5.8-6.2. Check EC not above 3.0. Confirm Cal-Nitrate was added last and fully dissolved.	Locked out below 5.5 or above 7.0
Purple / red leaf undersides	Phosphorus (P)	Check pH not below 5.0. Warm reservoir above 65°F. Usually resolves with pH correction.	Locked out below 5.0
Pale leaves, slow growth	Nitrogen — EC too low	Raise overall Masterblend dose by 0.4 g/gal. Check EC is above 1.4.	EC management
Dark green, thick leaves, stunted	Nitrogen excess — EC too high	Dilute reservoir. Partial water change. EC should not exceed 3.0 for peppers.	EC management
Curled, distorted new growth	Calcium (Ca) or Boron (B)	Confirm mixing order — Cal-Nitrate MUST go in last. If correct, try dilute boron foliar spray.	Ca locked out above 7.0

6 • Irrigation Schedule

RAINPOINT Timer Programming

Parameter	Setting
Cycle duration	10 minutes per cycle
Cycle interval	Every 8 hours — 3 cycles per day
Example schedule	6:00 AM / 2:00 PM / 10:00 PM
Minimum interval	8 hours — this is the shortest cycle interval the RAINPOINT timer supports. The system is locked to a maximum of 3 cycles per day.
Transplant stage	Reduce to 5 min / 8 hr for week 1. Step up to 10 min once roots are visibly active.

Stage	Cycles/Day	Duration	Notes
Transplant week 1	3	5 min	Keep medium moist, not saturated. Coco retains well — err toward drier.
Vegetative	3	10 min	Standard schedule. Coco/perlite holds moisture comfortably through 8-hour intervals.
Fruiting / peak	3	10 min	Standard schedule. Add manual cycle if wilting observed mid-interval.

Stage	Cycles/Day	Duration	Notes
June pre-monsoon (critical)	3 max	10 min	Highest risk period — 8-hr intervals may not be sufficient above 100°F. Monitor closely. Shade cloth and reservoir insulation are essential.
Peak summer heat (100°F+)	3 max	10 min	RAINPOINT cannot cycle more frequently. If wilting persists between cycles, shade cloth and reservoir cooling are the primary interventions. Consider supplemental midday pump (see note below).
Monsoon season (July–Sept)	3	10 min	Ambient temps drop and humidity rises — the 8-hr interval becomes very comfortable again. Rocoto and habanero hit peak production.

HOT MONTH LIMITATION: Because the RAINPOINT timer cannot cycle more frequently than every 8 hours, close monitoring of plants during June and peak summer heat events is required. Primary interventions when wilting is observed between cycles: (1) 30–50% shade cloth over buckets to reduce evapotranspiration, (2) insulate or shade the ACE reservoir tubs, (3) if persistent, add a second inexpensive hose timer (~\$15) connected to a second pump for a supplemental midday cycle.

Reading Runoff

Observation	Diagnosis
Target runoff	10-20% of feed volume — a steady drip from the low-end drain elbow after each 10-min cycle.
Zero runoff	Under-watering or clogged emitter. Check stakes immediately.
Excessive runoff	Cycle too long. Reduce to 7-8 min and observe.
Drain EC high	Roots drying out between cycles — increase duration before considering frequency.

7 • Maintenance

Daily Checks

- Confirm RAINPOINT solar panel is unobstructed and battery shows adequate charge.
- Verify all drip stakes are flowing during a cycle — walk the row and check for dry buckets.
- Check reservoir level — top off with plain pH-adjusted water between full nutrient changes.
- Log EC and pH daily — track drift direction to catch patterns before they damage plants.
- During hot months: check for wilting 4-5 hours after the morning cycle. Wilting before the next cycle is a heat stress signal requiring shade or reservoir cooling.

Weekly Tasks

- Full reservoir drain + fresh nutrient mix (every 7-10 days during fruiting).
- Flush 2×3 drain channel with clean water — root debris accumulates.
- Inspect and replace any clogged drip emitters.
- Check RAINPOINT intake filter screen — clear scale and sediment.
- Inspect high-end downspout elbow and cover — check for blockage or root intrusion.
- Soak RAINPOINT intake strainer in white vinegar — clears calcium scale from bulk nitrate.
- Wipe solar panel clean — dust and debris reduce charging efficiency.
- Check supply line tee fittings for drips or separation.
- Calibrate pH meter with buffer solution (pH 4.0 and 7.0) — inaccurate meters are the #1 cause of unexplained deficiencies.
- Check bench slope — settlement can reduce drainage over time.

End-of-Crop System Flush

1. **Drain and strip** — Drain reservoir. Pull plants, remove coco/perlite — coco is best replaced each season; perlite can be sanitised and reused.
2. **Water flush** — Fill with plain water and run RAINPOINT through several cycles to flush lines, stakes, and drain channel.
3. **H₂O₂ sanitise** — Mix 3 ml/gal of 3% hydrogen peroxide. Run through entire system once. Sit 15 min, then flush with plain water.
4. **Descale emitters** — Soak RAINPOINT intake screen and drip stakes in white vinegar 30 min. Rinse thoroughly. Calcium nitrate scale is the primary flow restrictor in this system.
5. **Clean buckets** — Rinse Cropping buckets — sloped floor drains completely. Flush downspout channel and inspect both elbows. Air dry before next crop.

8 • Materials & Rough Cost Breakdown

Estimated costs for a 20-bucket, 2-row build. Prices are approximate as of 2025.

Bench & Infrastructure (One-Time)

Item	Source	Est. Cost
Cropking Bato Buckets — case of 10 with elbows	cropking.com — free UPS shipping	~\$70-80 / case
20 buckets = 2 cases		~\$140-160 total
2×4×8 lumber (×4 per bench)	Home Depot / Lowes	~\$20-28 per bench
8×8×16 concrete building blocks (6 per bench)	Home Depot / Lowes	~\$25-35 per bench
2×3 vinyl downspout (10 ft lengths)	Home Depot / Lowes	~\$20-25 total
2×3 downspout elbows + end caps	Home Depot / Lowes	~\$12-18 total
RAINPOINT solar pump (B0DQ4DQL33)	amazon.com/dp/B0DQ4DQL33	\$35-50 each
15-gal ACE Hardware utility tub (×1-2)	ACE Hardware	~\$15-20 each
1/4" drip tubing + tee fittings + stakes	Amazon / irrigation supply	~\$15-25
pH meter + EC/TDS meter	Amazon	~\$25-55 total
2" hole saw bit	Home Depot / Amazon	~\$8-15
Infrastructure subtotal — 20 buckets, 2 rows		~\$315-490

Nutrients & Consumables (Per Season)

Item	Source	Est. Cost
Masterblend 4-18-38 — 25 lb bag	Amazon / powergrowsystems.com	~\$60-75
Calcium nitrate — 50 lb bag (bulk)	Amazon / local farm supply	~\$35-55
Epsom salt (magnesium sulfate) — 25 lb	Amazon / local	~\$15-25

Item	Source	Est. Cost
Coco coir — loose bag or compressed brick	ACE Hardware / Amazon bulk	~\$20-40
Perlite — large grade, 4 cu ft bag (×2-3)	ACE Hardware / Amazon bulk	~\$50-105
pH Down (citric acid or phosphoric acid)	Amazon / hydro shop	~\$10-18
pH Up (potassium hydroxide)	Amazon / hydro shop	~\$8-15
Replacement drip emitters (annual)	Amazon	~\$8-12
Consumables subtotal per season		~\$206-345

COST NOTE: Bulk Masterblend + calcium nitrate + Epsom salt costs under \$0.05 per gallon at 2025 bulk pricing. A 25 lb Masterblend bag paired with a 50 lb calcium nitrate bag produces approximately 2,000+ gallons of full-strength solution. The RAINPOINT solar pump eliminates the cost of a separate submersible pump (~\$25-50) and digital cycle timer (~\$20-40).

Where to Buy

Item	URL / Source
Cropking Bato Buckets (case of 10)	cropking.com/collections/bato-bucket-systems/products/bato-buckets-2-elbows
RAINPOINT Solar Pump (B0DQ4DQL33)	amazon.com/dp/B0DQ4DQL33
Masterblend 4-18-38 (25 lb)	amazon.com/dp/B071V8B4FL
Masterblend 3-part bulk combo kit	powergrowsystems.com — Masterblend Master Kit
Calcium nitrate 50 lb bulk	Amazon — search “calcium nitrate 50 lb hydroponic”
Coco coir + perlite	ACE Hardware (in-store) or Amazon bulk
2×3 vinyl downspout & elbows	Home Depot / Lowes — gutter & roofing section
8×8×16 concrete blocks	Home Depot / Lowes — masonry section
15-gal utility tub	ACE Hardware — black/yellow utility tub, in-store

Prices approximate as of 2025. Verify current pricing before purchasing. Nutrient programme adapted from the Dragoon Mountains Hydroponic Pepper Guide (Cochise County, Arizona). Water treatment protocol based on SE Arizona well water conditions.

The Dragoon Mountains go dry in May and dry again in October, and well water in Cochise County is stubbornly hard year-round. A bato bucket on a 2×4 bench and a 15-gallon reservoir solves both problems at once: every drop of water is pre-treated for bicarbonates, fed precisely at the right EC, and captured again on the drain side of the channel. This is how Rocoto and jalapeño keep producing when the monsoon is late, the well is salty, and the summer sun is at its hardest. Build the benches, treat the water, and the peppers will take care of themselves.