

NoFlat

INSTALLATION & DOSAGE GUIDE

Professional Installation Instructions

1. Remove the valve core and completely deflate the tire.
2. Break the bead and separate the tire from the rim.
3. Ensure the TPMS sensor is positioned on the opposite side of the application area.
4. Insert the NoFlat dispensing hose through the bead opening.
5. Add the recommended amount of NoFlat according to the tire size.
6. Reinstall the tire onto the rim and inflate it to the manufacturer's recommended pressure.
7. Drive immediately for approximately 6–10 miles at normal road speed to distribute the sealant evenly inside the tire.
8. Stop after approximately 10 minutes and verify the tire pressure. Adjust to the manufacturer's recommended pressure if necessary.

RECOMMENDED QUANTITY

Vehicle Type	Wheel Size	Recommended Quantity
Passenger Vehicles	13–15 in	23.7 fl oz
Passenger Vehicles	16–18 in	33.8 fl oz
Passenger Vehicles	19–23 in	43.9 fl oz
Commercial / Large Tires	Large Tires	54–68 fl oz

Important

Use only the recommended quantity. Do not install in tires with structural damage or sidewall cuts. Always follow the tire and vehicle manufacturer's service recommendations.