



USER MANUAL

SmogSpy Air Purifier

Complete Setup & Operation Guide

- WiFi 2.4GHz
- Blynk IoT
- 3 in 1 Monitoring
- Silent



DOCUMENT NO.
SS-APX-UM-001

VERSION
1.0 — 2026

LANGUAGE
English

© 2026 SmogSpy Technologies. All rights reserved. No part of this manual may be reproduced without prior written permission. Specifications subject to change without notice.

Table of Contents

1

Safety Instructions

3

2

Package Contents & Parts

3

3

Getting Started

4

3.1

Unboxing & Placement

4

3.2

First Power On

4

4

How to Use

5

4.1

Operating Modes

5

4.2

Control Panel Guide

5

4.3

Blynk IoT App Setup

5

4.4

Indicator Lights

6

5

Maintenance & Filter Replacement

6

5.1

Cleaning Schedule

6

5.2

Filter Replacement

7

6

Technical Specifications

7

7

Troubleshooting

8

8

Warranty & Support

8

SECTION 1

Safety Instructions

⚠️ READ ALL INSTRUCTIONS BEFORE USE

- Do not operate near water, bathtubs, sinks, or areas of high humidity.
- Do not insert fingers or objects into the air inlet or outlet vents.
- Keep out of reach of children under 3 years of age.
- Do not cover the device while in operation — ensure 20cm clearance on all sides.
- Use only the supplied power adapter. Do not exceed the rated voltage (6V–9V DC).
- Disconnect power before performing any cleaning or filter replacement.
- Do not attempt to disassemble or repair the unit yourself. Contact SmogSpy support.
- Do not use the device if the power cable is damaged or frayed.

SECTION 2

Package Contents & Parts

2.1 What's in the Box

1 SmogSpy Air Purifier Unit Main device × 1	2 DC Power Adapter 6V–9V, Barrel Jack 5.5×2.1mm × 1
3 HEPA H13 Filter Cartridge Pre-installed × 1	4 Carbon Filter Pre-installed × 1
5 Quick Start Guide Printed card × 1	6 Warranty Card Registration card × 1

2.2 Device Overview

A Air Inlet Vents Bottom & side mesh panels	B Air Outlet Top panel, 360° clean air output
C Control Panel Top-mounted touch buttons	D Air Quality Display CO₂, humidity & temperature readout
E Filter Access Panel Rear panel, press-tab release	F Power Port DC barrel jack, rear bottom

SECTION 3

Getting Started

3.1 Unboxing & Placement

- 1 Unbox your device.** Carefully open the box and remove the SmogSpy Air Purifier. Inside you will find the main unit, a power adapter, a filter cartridge, and a quick start guide.
- 2 Remove all packaging materials.** Peel off all protective plastic film from the unit's surface and remove the foam inserts from the air inlet and outlet vents before operating.
- 3 Choose a placement location.** Place the unit on a flat, stable surface. Ensure at least **20cm of clearance on all sides** for optimal airflow. Avoid placing near walls, curtains, or furniture that may block the vents.

 **Tip:** For best results, place SmogSpy in the center of the room or near the primary source of air pollution (e.g., near a kitchen, window, or pet area).

3.2 First Power On

- 4 Connect to power.** Insert the DC barrel jack into the power input port located at the rear bottom of the unit. Connect the adapter to a standard wall outlet. The indicator light will glow **red** on standby.
- 5 Power on the device.** Press and hold the power button for **3 seconds** until the indicator light turns blue. The fan will start at low speed and the display will show current air quality readings.
- 6 Allow warm-up time.** On first use, allow the unit to run for approximately 5 minutes to stabilize its CO₂ and humidity sensors for accurate readings.

 **Important:** Do not operate near water or in areas of high humidity above 85% RH. Keep out of reach of children under 3 years of age. Do not block the air outlet during operation.

SECTION 4

How to Use

4.1 Operating Modes

- 1

Auto Mode. In Auto Mode, the built-in CO₂ and humidity sensors continuously monitor your room's air quality and automatically adjust the fan speed to maintain a healthy environment. Press the **Mode** button once to activate.
- 2

Manual Speed Control. Press the fan speed button on the top panel to cycle through **Low**, **Medium**, and **High** settings. The current speed level is shown by the number of lit indicators on the front display.
- 3

Sleep / Night Mode. Press and hold the fan button for **2 seconds** to activate Sleep Mode. The unit will run at its lowest speed, dim all indicator lights, and operate near-silently for undisturbed rest.
- 4

Timer Settings. Press the Timer button to set an automatic shutoff in **2, 4, or 8 hour** intervals. The timer indicator on the front panel will blink once to confirm your selected duration.

4.2 Control Panel Guide

Button	Short Press	Long Press (2s)
 Power	—	Turn On / Off
 Fan Speed	Cycle Low → Mid → High	Activate Sleep Mode
 Mode	Toggle Auto / Manual	Lock control panel
 Timer	Cycle 2h → 4h → 8h → Off	Cancel active timer
 Filter Reset	—	Reset filter indicator (5s)

4.3 Blynk IoT App Setup

- 1

Download the **Blynk IoT** app from the Google Play Store or Apple App Store and create a free account.
- 2

In the app, tap **Add New Device** and select **SmogSpy Air Purifier** from the device list, or scan the QR code on the bottom of your unit.
- 3

Enter your home **WiFi credentials** (2.4GHz network only). The device indicator will blink blue rapidly during pairing, then glow solid blue once connected.
- 4

Once connected, the app dashboard will display **live CO₂ levels**, **humidity**, and **temperature** readings from your device in real time.

 **Note:** SmogSpy only supports 2.4GHz WiFi networks. 5GHz networks are not compatible. Ensure your phone is connected to the same 2.4GHz network during initial setup.

SECTION 5

Maintenance & Filter Replacement

5.1 Cleaning Schedule

Component	Frequency	Method
Pre-filter mesh	Every 2 weeks	Tap clean or rinse with water, air dry
Outer casing	Monthly	Wipe with dry or slightly damp cloth
Carbon filter	Every 3 months	Replace with genuine SmogSpy carbon filter
HEPA H13 filter	Every 6–12 months	Replace with genuine SmogSpy HEPA cartridge
Sensor area	Every 3 months	Gently blow with compressed air, no liquids

5.2 Filter Replacement Procedure

- 1 Power off and unplug.** Always disconnect the device from the power outlet before performing any filter maintenance.
- 2 Pre-filter cleaning (every 2 weeks).** Remove the back panel by pressing the release tabs on both sides. Pull out the pre-filter mesh and gently tap it to remove dust, or rinse with water and allow it to **fully dry** before reinserting.
- 3 Carbon filter replacement (every 3 months).** The carbon filter sits beneath the HEPA cartridge. Lift it out using the pull tab and replace with a new one. A noticeable reduction in odor absorption is a sign the carbon filter needs replacing sooner.
- 4 HEPA filter replacement (every 6–12 months).** With the back panel removed, slide out the HEPA filter cartridge by pulling the tab upward. Insert the new cartridge with the **airflow arrow pointing inward**, then reattach the back panel until it clicks.
- 5 Reset the filter indicator.** After replacing any filter, press and hold the **Filter Reset** button for 5 seconds until the indicator light blinks twice to confirm the reset.

 **Warning:** Only use genuine SmogSpy replacement filters. Third-party filters may void your warranty, reduce air purification performance, and potentially damage the unit's sensors.

SECTION 6

Technical Specifications

Physical		Performance	
Dimensions	145 × 95 × 50 mm	Filter Type	HEPA H13 + Activated Carbon
Weight	228 g	Filtration Efficiency	99.97% (≥0.3μm particles)
Housing Material	ABS Plastic	Noise Level	25 – 45 dB (Low – High)
Color Options	Pearl White, Sky Blue, Slate Gray	Fan Speeds	3 (Low / Medium / High)
Power		Connectivity & Sensors	
Input Voltage	6V – 9V DC	WiFi	2.4GHz 802.11 b/g/n
Connector	DC Barrel Jack 5.5 × 2.1 mm	App	Blynk IoT (Android / iOS)
Max Power	12W	Sensors	CO ₂ , Humidity, Temperature
Standby Power	< 0.5W	Display	LED indicator + digital readout

SECTION 7

Troubleshooting

Problem	Possible Cause	Solution
Device won't turn on	No power supply	Check adapter connection and wall outlet
WiFi won't connect	5GHz network selected	Switch router to 2.4GHz and retry pairing
Filter indicator is red	Filter replacement due	Replace filter and hold reset button 5 seconds
Unusual odor on first use	New filter off-gassing	Run on High for 30 min in ventilated room
Blynk app not updating	WiFi signal weak	Move device closer to router
Noisy operation	Foreign object in vent	Power off and check vents for obstructions

SECTION 8

Warranty & Support

8.1 Limited Warranty

SmogSpy Technologies warrants this product against defects in materials and workmanship for a period of **1 year** from the date of original purchase. This warranty covers manufacturing defects under normal use conditions and does not cover damage resulting from accident, misuse, unauthorized modification, or use of non-genuine replacement parts.

8.2 What is Covered

- ✓ Manufacturing defects in the main unit hardware
- ✓ Sensor malfunctions under normal operating conditions
- ✓ Fan motor failure not caused by foreign object damage
- ✓ Display and indicator light failures
- ✓ WiFi module connectivity failures

8.3 What is Not Covered

- ✓ Physical damage from drops, impacts, or liquid exposure
- ✓ Consumable parts (filters, pre-filter mesh) past replacement date
- ✓ Damage from use of non-genuine SmogSpy accessories or filters
- ✓ Normal wear and tear on exterior surfaces
- ✓ Products with removed or altered serial numbers

8.4 Contact & Support

**Email Support**
support@smogspy.com

**Phone Support**
[+62 123 4567] · 24/7

**Website**
www.smogspy.com/support

**Address**
123

REGISTER YOUR PRODUCT
Register your SmogSpy device at **www.smogspy.com/register** to activate your warranty and receive product updates and support notifications.

