

(HTTPS://TECHEXPLORATIONS.COM/SO/KICADA/)

# KICAD LIKE A PRO (COVERS KICAD VERSION 4)

(INDEX-PAGE\_ID=309.HTML)

A WEB PROJECT-BASED COURSE FROM TECH EXPLORATIONS

(INDEX-PAGE\_ID=309.HTML)

## **GET THE EBOOK AND VIDEO COURSE, UPDATED FOR KICAD 5.1**


(HTTPS://TECHEXPLORATIONS.COM/SO/KICADA/)

Hidden pins and the power flag Home (index-page\_id=309.html) / Hidden pins and the power flag

PROJECT 2: A SEVEN-SEGMENT DISPLAY (INDEX-CAT=12.HTML)


## HIDDEN PINS AND THE POWER FLAG

In this chapter I will explain the concept of hidden pins. To do this, let's concentrate on the 595 integrated circuit. This IC is interesting because it contains hidden pins.




Take a close look at the 595 component. The power pins are not visible. They do exist in the schematic, but they are invisible.

You can see here that unlike the real 595 part, there are two pins that are missing, those are the power pins. The real 595 part has one pin for Vcc and one pin for GND. In the Kicad schematic component for the 595 IC, you can make those pins visible by going to the schematic editor options and clicking on show hidden pins.




### To make hidden pins visible, go to Preferences, Schematic Editor Options...



...Check the "Show hidden pins" option, and click OK.

When you do that, you'll see pin 8, and pin 16, which are VCC and ground respectively.




#### The hidden pins are revealed.

Hidden pins are... hidden because KiCad expects that somewhere in your schematic are nets that are marked as power nets. In the background, Kicad will automatically connect pin 8 and pin 16 to those nets. In our schematic, we already have Vcc and GND nets, but they're not marked as power nets yet.

Before we mark the power nets, restore hidden pins to their default state so that that they are invisible.


In order to mark a net or a connection or wire as a power net, you will need to use the power flag. The power flag is just another component, except that it is not really an electrical component. It's a KiCad component, or a component that KiCad uses with its rules check to confirm that hidden pins that require power are indeed connected to a power net.

Hit the "A" key to bring up the component chooser, and use the filter to search for the power flag. Type "PWD".



## Use the filter to find the PWR\_FLAG component in the components chooser.

Double click to drop the component to the canvas. Place it next to the GND net (wire) and use a wire to connect the flag to the GND net. Ensure that a solid green circle marks the joint (no circle means no connection). Repeat the process for the Vcc net, so that this is also marked with a PWR\_FLAG. You should end up with something like this:



#### The GND and Vcc nets are marked with the PWR\_FLAG.

If you do an ERC now, you will get error reporting that various pins are not connected to anything, but you will not get any errors concerning the GND or Vcc hidden pins of the IC. Those are now connected to the GND and Vcc nets in the background because Kicad is informed of their existence.

With this taken care of, let's move to the next objective: connecting the data pins of the IC to the resistors and the LEDs. We could use normal wires to do this, but you can imagine that the schematic would be very busy. Instead, we will setup a data bus. In the next chapter, I will show you how to make multiple connections using a data bus.

Back to top

« « Create nets and labels (index-p=153.html) | The data bus (index-p=155.html) » »

#### GO TO CHAPTER...

Introduction (index-cat=2.html)

What is Kicad? (index-p=34.html)

The structure of this course (index-p=36.html)

Kicad bacis (index-cat=6.html)

Kicad basics introduction (index-p=38.html)

Installation for Microsoft Windows (index-p=41.html)

Installation on Mac OS X (index-p=56.html)

Kicad main components (index-p=71.html)

Finding documentation (index-p=75.html)

What is a Printed Circuit Board? (index-p=76.html)

The Kicad design process (index-p=81.html)

Project 1: An nRF24 breakout (index-cat=9.html)

Section introduction (index-p=83.html)

Creating a new project (index-p=85.html)

Starting the schematic for the nRF24 (index-p=84.html)

How to create a schematic component (index-p=96.html)

Wiring in Eeschema (index-p=97.html)

Annotating the schematic (index-p=100.html)

Electrical Rules Check (index-p=99.html)

Associate components to footprints (index-p=98.html)

Create a custom footprint (index-p=111.html)

Saving the new footprint (index-p=112.html)

Associate the new footprint and component (index-p=116.html)

Create a netlist (index-p=115.html)

Footprints placement (index-p=114.html)

Edge cuts (index-p=113.html)

Wiring in Pcbnew (index-p=128.html)

Add text labels (index-p=131.html)

Project 1: Enhancing the design (index-cat=10.html)

Section introduction (index-p=129.html)

Add a capacitor to the layout in Pcbnew (index-p=130.html)

Add a capacitor to the layout in Pcbnew (index-p=130.html)

Controlling the track width (index-p=127.html)

Calculate the appropriate track width (index-p=146.html)

Adding copper fills (index-p=147.html)

Project 1: fabricating the PCB (index-cat=11.html)

Section introduction (index-p=149.html)

Creating the Gerber files and uploading to fabricator (index-p=151.html)

Adding a decorative graphic (index-p=148.html)

The unconnected component (index-p=154.html)

Project 2: a seven-segment display (index-cat=12.html)

Section Introduction (index-p=150.html)

Create the schematic in Eeschema (index-p=187.html)

Create nets and labels (index-p=153.html)

Hidden pins and the power flag (index-p=156.html)

The data bus (index-p=155.html)

Component – footprint associations (index-p=157.html)

Create a 2 layer PCB in Pcbnew (index-p=181.html)

Control track widths with nets (index-p=180.html)

Add GND and Vcc copper fills (index-p=189.html)

Add text labels (index-p=184.html)

Adding a decorative graphic (index-p=148.html)

Exporting Gerber files (index-p=185.html)

Project 3: a 16-led display with shift registers (index-cat=13.html)

Section Introduction (index-p=186.html)

The circuit (index-p=183.html)

Create the schematic in Eeschema (index-p=187.html)

Schematic wiring, Part 1 (index-p=188.html)

Schematic wiring, Part 2 (index-p=204.html)

Associate components with footprints (index-p=206.html)

Create the PCB in Pcbnew (index-p=205.html)

Wiring in Pcbnew (index-p=208.html)

Adding copper fills (index-p=207.html)

Adding text labels and decorative graphics (index-p=209.html)

Export the Gerber files (index-p=220.html)

Conclusion (index-cat=14.html)

This site contains the eBook version of KiCad Like a Pro, 1st edition, and covers KiCad 4. The 2nd edition of KiCad Like a Pro is now available (https://techexplorations.com/so/kicada/), which covers KiCad 5.1. Have a look at all of our courses and books (https://techexplorations.com).