
7.18 Base MIPSzy + sub


A designer can extend the base MIPSzy to support the sub (subtract) instruction. The designer can include the sub instruct behavioral description. As a reminder, the add and sub instructions have the same opcode bits ir31_26 of 000000 but have function bits ir5_0 of 100000 (add) and 100010 (sub).

Table 7.18.1: Reminder: MIPSzy machine instructions for add and sub.

Assembly	Machine
add \$t0, \$t1, \$t2	000000 01001 01010 01000 00000 100000
sub \$t0, \$t1, \$t2	000000 01001 01010 01000 00000 100010

To support the behavioral description's actions in the processor's circuit, the designer can replace ADD with an ADD/SUB or performs addition when the component's control input sub is 0, and subtraction when sub is 1. Then CTRL sets the componentiately for each of the add and sub instructions.





PARTICIPATION ACTIVITY

7.18.2: Extending the base MIPSzy with the sub instruction.

- 1) In the base MIPSzy from a previous section, the add instruction's control logic actions set the add_sub control signal with 0.
 - O True
 - O False
- 2) In the base MIPSzy extended for sub, the add instruction's control logic


actions set the add_sub control signal with 0.

O True
O False

3) In the base MIPSzy extended for sub, the sub instruction's control logic actions set the add_sub control signal with 1.

O True
O False

CHALLENGE 7.18.1: Subtraction extension in MIPSzy. **ACTIVITY** Start Enter the bits for each item. asm: add \$t7, \$t1, \$t5 ir: 000000 01001 01101 01111 0



Provide feedback on this section