Aspen SIM800 Library Documentation

Copyright (C) 2016 Mattias Aabmets
(https://github.com/aspenforest)

The SIM800 models which this library should work with are documented in the official AT command manual. SIM800L has been tested to work with this library.

All public methods accessible to the user are separated into helper methods and AT methods. Each must be called on the single SIM800 class object instance named "SIM". Example: SIM.test();

Helper methods are used to either modify the input/output to/from the SIM800L chip, or to directly communicate with it.

All AT methods require at most two args, which can be either an enum called CmdType (CT) with valid values of TEST, GET, SET, EXE, and/or a parameter char[]. Some AT methods take no args, or no CT, or no char[], or two char[]. The user is responsible for providing correct format and values for the char[] parameter(s).

The user should consult with the official AT command manual to determine what CmdTypes and what char[] parameter options are available for each AT command.

The core source files are internally very well commented and users are encouraged to read them to gain a complete understanding of this library.

It's recommended to read the comments in the following order: SIM800.h, SIM800.cpp, simserial.h, simserial.cpp, strfn.h, strfn.cpp, debug.h, debug.cpp.

Helper methods overview			
void begin (unsigned long)	void setSlicePoint (uint32_t)		
void write (char[])	void directSerialMonitor ()		
void print (char[])	void cmdBenchmark (bool)		
void available ()	bool reply (char[])		
<pre>void setTimeout (uint16_t)</pre>	bool isError ()		
<pre>void resetTimeout ()</pre>	char[] getBuffer ()		
uint16_t getTimeout ()	void clearBuffer ()		
void detectEndStr (bool)	void formatReply (bool)		
<pre>void overrideTimeout (uint16_t</pre>			

Nº	AT method	Args	AT command	Ofc man		
	calls.h					
1.	test	-	АТ	-		
2.	repeatLastCmd	-	Α/	28		
3.	answerCall	-	ATA	28		
4.	originCall	[]	ATD	29		
5.	redialLastAddr	-	ATDL	34		
6.	setCmdEcho	[]	ATE	35		
7.	endCall	-	АТН	35		
8.	getDeviceID	-	ATI	35		
9.	monSpeakerVol	[]	ATL	36		
10.	monSpeakerMode	[]	ATM	36		
11.	toCmdMode	-	+++	36		
12.	toDataMode	-	AT0	37		
13.	pulseDialing	-	АТР	37		
14.	setResultMode	[]	ATQ	38		
15.	autoAnswerAfter	CT,[]	ATS0	38		
16.	cmdlnEndChar	-	ATS3	39		
17.	cmdlnFormatChar	-	ATS4	39		
18.	cmdlnEditChar	-	ATS5	40		
19.	blindDialPause	СТ,[]	ATS6	41		
20.	connWaitTime	СТ,[]	ATS7	41		
21.	commaWaitTime	СТ,[]	ATS8	42		
22.	carrierLostDelay	CT,[]	ATS10	42		
23.	toneDialing	-	ATT	43		
24.	setResponseFormat	[]	ATV	43		
25.	setCallMonitor	[]	ATX	44		
26.	userReset	-	ATZ	45		
27.	setDcdMode	[]	AT&C	45		
28.	setDtrMode	[]	AT&D	46		
29.	factoryReset	-	AT&F	46		

Nº	AT method	Args	AT command	Ofc man	
	calls.h				
30.	getActiveCfg	-	AT&V	47	
31.	saveActiveCfg	-	AT&W	47	
32.	getGsmSupport	-	AT+GCAP	49	
33.	getMakerID	TEST, EXE	AT+GMI	49	
34.	getDeviceModelID	TEST, EXE	AT+GMM	50	
35.	getSoftwareID	TEST, EXE	AT+GMR	50	
36.	getGOI	TEST, EXE	AT+G0I	51	
37.	getIMEI	TEST, EXE	AT+GSN	51	
38.	serialFraming	CT,[]	AT+ICF	52	
39.	serialFlowCtrl	CT,[]	AT+IFC	53	
40.	serialBauds	CT,[]	AT+IPR	54	
41.	endCallOnly	-	AT+HVOIC	55	
		sms.h			
42.	smsDel	CT,[]	AT+CMGD	112	
43.	smsFormat	CT,[]	AT+CMGF	113	
44.	smsList	CT,[]	AT+CMGL	114	
45.	smsRead	CT,[]	AT+CMGR	117	
46.	smsSend	[],[]	AT+CMGS	120	
47.	smsWriteToStore	[],[]	AT+CMGW	121	
48.	smsSendFromStore	CT,[]	AT+CMSS	123	
49.	smsNotifyNew	CT,[]	AT+CNMI	124	
50.	smsStorage	CT,[]	AT+CPMS	126	
51.	smsRestoreCfg	CT,[]	AT+CRES	127	
52.	smsSaveCfg	CT,[]	AT+CSAS	128	
53.	smsCenterAddress	CT,[]	AT+CSCA	129	
54.	smsCellCast	CT,[]	AT+CSCB	130	
55.	smsGetParams	CT,[]	AT+CSDH	131	
56.	smsSetParams	CT,[]	AT+CSMP	132	
57.	smsService	CT,[]	AT+CSMS	133	

Nº	AT method	Args	AT command	Ofc man
		gprs.h		
58.	gprsAttach	CT,[]	AT+CGATT	208
59.	gprsDefineContext	CT,[]	AT+CGDCONT	209
60.	gprsMinQuality	CT,[]	AT+CGQMIN	210
61.	gprsReqQuality	СТ,[]	AT+CGQREQ	210
62.	gprsEnactContext	CT,[]	AT+CGACT	213
63.	gprsDataState	CT,[]	AT+CGDATA	214
64.	gprsAddress	CT,[]	AT+CGPADDR	214
65.	gprsStationClass	CT,[]	AT+CGCLASS	215
66.	gprsReportCtrl	CT,[]	AT+CGEREP	216
67.	gprsRegStatus	СТ,[]	AT+CGREG	217
68.	gprsMsgService	СТ,[]	AT+CGSMS	218
		ip.h		
69.	ipMultiConn	СТ,[]	AT+CIPMUX	221
70.	ipOpen	СТ,[]	AT+CIPSTART	221
71.	ipSend	CT,[]	AT+CIPSEND	223
72.	ipQuicksend	CT,[]	AT+CIPQSEND	225
73.	ipAck	CT,[]	AT+CIPACK	226
74.	ipClose	CT,[]	AT+CIPCLOSE	227
75.	ipDeactivate	TEST, EXE	AT+CIPSHUT	227
76.	ipPort	СТ,[]	AT+CLPORT	228
77.	ipAccess	CT,[]	AT+CSTT	229
78.	ipBegin	TEST, EXE	AT+CIICR	230
79.	ipGetLocalAddr	TEST, EXE	AT+CIFSR	230
80.	ipStatus	CT,[]	AT+CIPSTATUS	231
81.	ipDnsCfg	CT,[]	AT+CDNSCFG	232
82.	ipGetNameAddr	CT,[]	AT+CDNSGIP	233
83.	ipAddHead	CT,[]	AT+CIPHEAD	234
84.	ipAutoSendTimer	CT,[]	AT+CIPATS	234
85.	ipSendPrompt	CT,[]	AT+CIPSPRT	235

Nº	AT method	Args	AT command	Ofc man
		ip.h		'
86.	ipServer	СТ,[]	AT+CIPSERVER	236
87.	ipConnMode	СТ,[]	AT+CIPCSGP	237
88.	ipShowRemoteID	СТ,[]	AT+CIPSRIP	238
89.	ipNetTiming	СТ,[]	AT+CIPDPDP	239
90.	ipAppMode	СТ,[]	AT+CIPMODE	239
91.	ipTransferCfg	СТ,[]	AT+CIPCCFG	240
92.	ipShowProtocol	СТ,[]	AT+CIPSHOWTP	241
93.	ipUdpMode	СТ,[]	AT+CIPUDPMODE	242
94.	ipManualData	СТ,[]	AT+CIPRXGET	243
95.	ipSaveCfg	GET, EXE	AT+CIPSCONT	245
96.	ipRemoteTimer	СТ,[]	AT+CIPRDTIMER	246
97.	ipMultiPdpCfg	СТ,[]	AT+CIPSGTXT	247
98.	ipKeepAlive	СТ,[]	AT+CIPTKA	248
99.	ipBearer	СТ,[]	AT+SAPBR	249
100.	ipPing	СТ,[]	AT+CIPPING	251
101.	ipEchoReply	СТ,[]	AT+CIPCTL	252
102.	ipFilter	СТ,[]	AT+CIPFLT	253
103.	ipAnswerPings	СТ,[]	AT+CIPBEIPING	254
104.	ipGsmLoc	СТ,[]	AT+CIPGSMLOC	288
		http.h		
105.	httpInit	TEST, EXE	AT+HTTPINIT	256
106.	httpEnd	TEST, EXE	AT+HTTPTERM	257
107.	httpParams	СТ,[]	AT+HTTPPARA	257
108.	httpData	СТ,[]	AT+HTTPDATA	259
109.	httpAction	СТ,[]	AT+HTTPACTION	259
110.	httpRead	СТ,[]	AT+HTTPREAD	261
111.	httpSave	GET, EXE	AT+HTTPSCONT	262
112.	httpStatus	TEST, GET	AT+HTTPSTATUS	263
113.	httpHeader	TEST, EXE	AT+HTTPHEAD	264

Nº	AT method	Args	AT command	Ofc man
		general.h		•
114.	callMeter	CT,[]	AT+CACM	57
115.	callMeterMax	CT,[]	AT+CAMM	58
116.	chargeAdvice	CT,[]	AT+CAOC	59
117.	dataCallService	CT,[]	AT+CBST	60
118.	callForward	CT,[]	AT+CCFC	61
119.	callWait	CT,[]	AT+CCWA	63
120.	errorReport	CT,[]	AT+CEER	64
121.	reqMakerID	TEST, EXE	AT+CGMI	67
122.	reqDeviceModelID	TEST, EXE	AT+CGMM	67
123.	reqSoftwareID	TEST, EXE	AT+CGMR	68
124.	reqIMEI	TEST, EXE	AT+CGSN	68
125.	charset	CT,[]	AT+CSCS	69
126.	addressType	CT,[]	AT+CSTA	70
127.	callHold	CT,[]	AT+CHLD	70
128.	reqIMSI	TEST, EXE	AT+CIMI	71
129.	activeCalls	CT,[]	AT+CLCC	72
130.	facilityLock	CT,[]	AT+CLCK	73
131.	showCallerID	CT,[]	AT+CLIP	75
132.	hideSelfID	CT,[]	AT+CLIR	76
133.	deviceError	CT,[]	AT+CMEE	77
134.	callerID	CT,[]	AT+COLP	78
135.	netOps	CT,[]	AT+COPS	80
136.	activity	TEST, EXE	AT+CPAS	81
137.	pbFind	CT,[]	AT+CPBF	82
138.	pbRead	CT,[]	AT+CPBR	83
139.	pbStorage	CT,[]	AT+CPBS	84
140.	pbWrite	CT,[]	AT+CPBW	85
141.	pinCode	CT,[]	AT+CPIN	86
142.	changePwd	CT,[]	AT+CPWD	87

Nº	AT method	Args	AT command	Ofc man
		general.h		•
143.	serviceReport	CT,[]	AT+CR	88
144.	ringCodeMode	CT,[]	AT+CRC	89
145.	netReg	CT,[]	AT+CREG	90
146.	radioLinkParams	CT,[]	AT+CRLP	92
147.	simRawAccess	CT,[]	AT+CRSM	92
148.	signalQuality	TEST, EXE	AT+CSQ	93
149.	dtmfDuration	CT,[]	AT+VTD	94
150.	dtmfPlay	CT,[]	AT+VTS	95
151.	muxControl	CT,[]	AT+CMUX	96
152.	getSelfAddr	TEST, EXE	AT+CNUM	97
153.	pref0perators	CT,[]	AT+CPOL	98
154.	listAllOperators	TEST, EXE	AT+COPN	99
155.	deviceMode	CT,[]	AT+CFUN	100
156.	clock	CT,[]	AT+CCLK	101
157.	simStrAccess	CT,[]	AT+CSIM	101
158.	alertMode	CT,[]	AT+CALM	102
159.	alertSound	CT,[]	AT+CALS	103
160.	ringerVolume	CT,[]	AT+CRSL	104
161.	loudSpeakerVol	CT,[]	AT+CLVL	104
162.	mute	CT,[]	AT+CMUT	105
163.	pricePerUnit	CT,[]	AT+CPUC	106
164.	callMeterMaxEvent	CT,[]	AT+CCWE	107
165.	battery	TEST, EXE	AT+CBC	108
166.	usd	CT,[]	AT+CUSD	108
167.	ssn	CT,[]	AT+CSSN	109
168.	dtmfDetect	CT,[]	AT+DDET	333

Nº	AT method	Args	AT command	Ofc man
•		simcom.h		•
169.	sideToneGain	CT,[]	AT+SIDET	145
170.	powerOff	[]	AT+CPOWD	146
171.	pinCodeTriesLeft	-	AT+SPIC	146
172.	micGain	СТ,[]	AT+CMIC	146
173.	alarmTime	СТ,[]	AT+CALA	148
174.	delAlarm	СТ,[]	AT+CALD	149
175.	readAdc	TEST, GET	AT+CADC	149
176.	singleNumScheme	СТ,[]	AT+CSNS	150
177.	resetCellCast	-	AT+CDSCB	151
178.	cfgAltModeCalls	CT,[]	AT+CMOD	151
179.	riPinUrc	CT,[]	AT+CFGRI	151
180.	timeStamp	CT,[]	AT+CLTS	152
181.	dtmfLocalTone	CT,[]	AT+CLDTMF	154
182.	indicateCallEnd	СТ,[]	AT+CDRIND	155
183.	serviceProvider	-	AT+CSPN	156
184.	voiceMail	СТ,[]	AT+CCVM	156
185.	opBand	CT,[]	AT+CBAND	157
186.	handsFree	CT,[]	AT+CHF	158
187.	swapAudio	CT,[]	AT+CHFA	159
188.	slowClock	CT,[]	AT+CSCLK	160
189.	engMode	CT,[]	AT+CENG	161
190.	smsZeroToSIM	СТ,[]	AT+SCLASS0	163
191.	simCardID	TEST, EXE	AT+CCID	164
192.	temperature	CT,[]	AT+CMTE	164
193.	delAllMsg	СТ,[]	AT+CMGDA	165
194.	stkPlayTone	СТ,[]	AT+STTONE	166
195.	toneGen	СТ,[]	AT+SIMTONE	167
196.	alphaString	СТ,[]	AT+CCPD	168
197.	simGroupID	-	AT+CGID	168

Nº	AT method	Args	AT command	Ofc man
		simcom.h	1	•
198.	originCallState	CT,[]	AT+MORING	169
199.	smsHexMode	СТ,[]	AT+CMGHEX	170
200.	smsDeviceCompat	СТ,[]	AT+CCODE	170
201.	cfgInitUrc	СТ,[]	AT+CIURC	171
202.	setSuperPwd	[]	AT+CPSPWD	172
203.	signalQualityURC	CT,[]	AT+EXUNSOL	172
204.	gprsMultiClass	CT,[]	AT+CGMSCLASS	173
205.	getFlashMemType	-	AT+CDEVICE	174
206.	queryCallReady	TEST, GET	AT+CCALR	174
207.	getPII	-	AT+GSV	174
208.	gpioCtrl	CT,[]	AT+SGPIO	175
209.	pwmGen	CT,[]	AT+SPWM	176
210.	echoCtrl	CT,[]	AT+ECHO	176
211.	autoAudioSwitch	CT,[]	AT+CAAS	177
212.	voiceEncoderCtrl	CT,[]	AT+SVR	178
213.	gsmBusy	CT,[]	AT+GSMBUSY	179
214.	emergencyNumList	CT,[]	AT+CEMNL	180
215.	arfcnLock	CT,[]	AT*CELLLOCK	181
216.	netLightPeriod	CT,[]	AT+SLEDS	182
217.	buzzerRingtone	CT,[]	AT+CBUZZERRING	183
218.	micCtrl	CT,[]	AT+CEXTERNTONE	183
219.	netLight	CT,[]	AT+CNETLIGHT	184
220.	whiteList	CT,[]	AT+CWHITELIST	185
221.	detectSimCard	CT,[]	AT+CSDT	186
222.	simPresent	CT,[]	AT+CSMINS	186
223.	gprsNetLight	CT,[]	AT+CSGS	187
224.	micBias	CT,[]	AT+CMICBIAS	188
225.	playAudioIntoCall	CT,[]	AT+DTAM	189
226.	detectJamming	CT,[]	AT+SJDR	189

Nº	AT method	Args	AT command	Ofc man
•		simcom.h	•	•
227.	pcmCfg	СТ,[]	AT+CPCMCFG	191
228.	pcmSyncParam	CT,[]	AT+CPCMSYNC	192
229.	detectAntenna	CT,[]	AT+CANT	193
230.	agcCfg	CT,[]	AT+CAGCSET	194
231.	pcmSwitchSD	CT,[]	AT+SD2PCM	194
232.	detectKeypad	CT,[]	AT+SKPD	194
233.	toneStringGen	CT,[]	AT+SIMTONEX	196
234.	roamingState	-	AT+CROAMING	197
235.	netScan	СТ,[]	AT+CNETSCAN	197
236.	dualSerialPort	CT,[]	AT+CMNRP	198
237.	edgeCfg	СТ,[]	AT+CEGPRS	199
238.	gpioIndex	CT,[]	AT+CGPIO	200
239.	playAudio	СТ,[]	AT+CMEDPLAY	201
240.	audioVolume	CT,[]	AT+CMEDIAVOL	202
241.	atcmdSoundLevel	CT,[]	AT+SNDLEVEL	202
242.	chargeCtrl	CT,[]	AT+ECHARGE	203
243.	simPollInterval	CT,[]	AT+SIMTIMER	204
244.	enhanceSpeech	CT,[]	AT+SPE	204
245.	getConcatMsgIndex	TEST, EXE	AT+CCONCINDEX	205
246.	sdModeSwitch	CT,[]	AT+SDMODE	205
247.	smsResendCtrl	СТ,[]	AT+SRSPT	206
248.	record	СТ,[]	AT+CREC	335
249.	recordToUart	СТ,[]	AT+CRECORD	338
250.	textToSpeech	СТ,[]	AT+CTTS	340
251.	textToSpeechCfg	СТ,[]	AT+CTTSPARAM	341
252.	textToSpeechRing	CT,[]	AT+CTTSRING	342

Nº	AT method	Args	AT command	Ofc man
		ftp.h	•	•
253.	ftpPort	CT,[]	AT+FTPPORT	266
254.	ftpMode	CT,[]	AT+FTPMODE	266
255.	ftpDataType	CT,[]	AT+FTPTYPE	267
256.	ftpPutMode	CT,[]	AT+FTPPUT0PT	268
257.	ftpBearerID	CT,[]	AT+FTPCID	268
258.	ftpResume	CT,[]	AT+FTPREST	269
259.	ftpServerAddr	CT,[]	AT+FTPSERV	269
260.	ftpUsername	CT,[]	AT+FTPUN	270
261.	ftpPassword	CT,[]	AT+FTPPW	271
262.	ftpDownName	CT,[]	AT+FTPGETNAME	272
263.	ftpDownPath	CT,[]	AT+FTPGETPATH	272
264.	ftpUpName	CT,[]	AT+FTPPUTNAME	273
265.	ftpUpPath	CT,[]	AT+FTPPUTPATH	273
266.	ftpGetFile	CT,[]	AT+FTPGET	274
267.	ftpPutFile	CT,[]	AT+FTPPUT	275
268.	ftpSaveCfg	GET, EXE	AT+FTPSCONT	276
269.	ftpDelFile	TEST, EXE	AT+FTPDELE	277
270.	ftpFileSize	TEST, EXE	AT+FTPSIZE	278
271.	ftpState	TEST, EXE	AT+FTPSTATE	279
272.	ftpExtPutfile	CT,[]	AT+FTPEXTPUT	279
273.	ftpMakeDir	TEST, EXE	AT+FTPMKD	280
274.	ftpDelDir	TEST, EXE	AT+FTPRMD	281
275.	ftpListFiles	CT,[]	AT+FTPLIST	281
276.	ftpGetToFS	CT,[]	AT+FTPGETTOFS	282
277.	ftpPutFromFS	CT,[]	AT+FTPPUTFRMFS	283
278.	ftpExtGetfile	CT,[]	AT+FTPEXTGET	285
279.	ftpPutFromRAM	CT,[]	AT+FTPFILEPUT	286
280.	ftpQuit	TEST, EXE	AT+FTPQUIT	287

Nº	AT method	Args	AT command	Ofc man
		email.h		•
281.	mailBearerID	CT,[]	AT+EMAILCID	291
282.	mailTimeout	СТ,[]	AT+EMAILTO	291
283.	smtpServer	СТ,[]	AT+SMTPSRV	292
284.	smtpAuth	СТ,[]	AT+SMTPAUTH	293
285.	smtpFrom	СТ,[]	AT+SMTPFROM	294
286.	smtpTo	СТ,[]	AT+SMTPRCPT	295
287.	smtpSubject	СТ,[]	AT+SMTPSUB	296
288.	smtpBody	СТ,[]	AT+SMTPBODY	296
289.	smtpFile	СТ,[]	AT+SMTPFILE	297
290.	smtpSend	TEST, EXE	AT+SMTPSEND	298
291.	smtpFilesend	СТ,[]	AT+SMTPFT	299
292.	smtpCharset	СТ,[]	AT+SMTPCS	300
293.	popCfg	СТ,[]	AT+P0P3SRV	301
294.	popLogin	TEST, EXE	AT+P0P3IN	302
295.	popInbox	TEST, EXE	AT+POP3NUM	302
296.	popMailSize	СТ,[]	AT+P0P3LIST	303
297.	popMailUID	СТ,[]	AT+P0P3UIDL	304
298.	popMultiGet	СТ,[]	AT+P0P3CMD	305
299.	popMultiRead	СТ,[]	AT+P0P3READ	307
300.	popMarkDel	СТ,[]	AT+P0P3DEL	308
301.	popUnmarkDel	TEST, EXE	AT+P0P3RSET	309
302.	popLogout	TEST, EXE	AT+P0P30UT	310

Nº	AT method	Args	AT command	Ofc man		
mms.h						
303.	mmsCenterUrl	СТ,[]	AT+CMMSCURL	312		
304.	mmsProxy	СТ,[]	AT+CMMSPROTO	312		
305.	mmsNetwork	СТ,[]	AT+CMMSCID	313		
306.	mmsCfgSend	СТ,[]	AT+CMMSSENDCFG	314		
307.	mmsEdit	СТ,[]	AT+CMMSEDIT	315		
308.	mmsDownFile	СТ,[]	AT+CMMSDOWN	316		
309.	mmsDelFile	СТ,[]	AT+CMMSDELFILE	317		
310.	mmsSend	CT,[]	AT+CMMSSEND	318		
311.	mmsAddRecp	CT,[]	AT+CMMSRECP	319		
312.	mmsAddCopyRecp	CT,[]	AT+CMMSCC	319		
313.	mmsAddCopyRecp	CT,[]	AT+CMMSBCC	320		
314.	mmsDelRecp	СТ,[]	AT+CMMSDELRECP	321		
315.	mmsDelCopyRecp	СТ,[]	AT+CMMSDELCC	321		
316.	mmsDelBccRecp	СТ,[]	AT+CMMSDELBCC	322		
317.	mmsGet	СТ,[]	AT+CMMSRECV	323		
318.	mmsDetails	TEST, GET, EXE	AT+CMMSVIEW	324		
319.	mmsRead	СТ,[]	AT+CMMSREAD	325		
320.	mmsReadPush	СТ,[]	AT+CMMSRDPUSH	325		
321.	mmsUserAgent	СТ,[]	AT+CMMSUA	327		
322.	mmsUserProfile	СТ,[]	AT+CMMSPROFILE	328		
323.	mmsTimeout	СТ,[]	AT+CMMSTIMEOUT	328		
324.	mmsStatus	TEST, GET	AT+CMMSSTATUS	329		
325.	mmsBegin	TEST, EXE	AT+CMMSINIT	330		
326.	mmsEnd	TEST, EXE	AT+CMMSTERM	330		
327.	mmsSaveCfg	TEST, GET, EXE	AT+CMMSSCONT	331		

Nº	AT method	Args	AT command	Ofc man		
stk.h						
328.	stkReply	СТ,[]	AT+STKTRS	135		
329.	stkEnvelope	СТ,[]	AT+STKENVS	136		
330.	stkCallSetup	СТ,[]	AT+STKCALL	137		
331.	stkSms	СТ,[]	AT+STKSMS	138		
332.	stkSetupSS	СТ,[]	AT+STKSS	138		
333.	stkSetupUSSD	СТ,[]	AT+STKUSSD	139		
334.	stkSendDTMF	СТ,[]	AT+STKDTMF	139		
335.	stkMenu	СТ,[]	AT+STKMENU	141		
336.	stkSetURC	CT,[]	AT+STKPCIS	141		