1 Comp. Loc. Relays

- ♦ ⇒ R1.1 elays on E-box ", page 1
- ◆ ⇒ o1.2 n upper Vehicle Electrical Module ", page 4
- ◆ ⇒ o1.3 n lower Vehicle Electrical Module ", page 8
- ♦ ⇒ R1.4 elays on Auxiliary Relay Carrier ", page 13

1.1 Relays on E-box

- ♦ ⇒ o1.1.1 n E-Box, MY 2010", page 1
- ♦ ⇒ o1.1.2 n E-Box, MY 2011", page 2
- ♦ ⇒ o1.1.3 n E-Box, through late 2011 MY forward", page 3

1.1.1 Relay on E-Box, MY 2010

R1 - Motronic engine control module power supply relay -J271- (100) Connection 1.1 Engine codes CAVD, CAXA, CAWB, CCZA and CGGA R1 - Terminal 30 power supply relay -J317- (458) Connection 1.1 Engine codes BXE, CAYB, CAYC, CBDA, CBDB and CEGA

R1 - Simos control module power supply relay -J363- (458)

K1 - 3	olmos c	ontroi	module	power	supply	relay	- J3
	Conne	ction 1	1.1				

☐ Engine codes BSE, BSF and CCSA

R2 - Secondary air pump relay -J299- (100)

☐ Connection 2.2

☐ Engine codes BSE, BSF and CCSA

R2 - Auxiliary engine coolant pump relay -J496- (100)

☐ Connection 2.2

☐ Engine codes CAVD and CAXA,

R2 - Engine component current supply relay -J757- (100)

☐ Connection 2.2


☐ Engine codes CAWD and CCZA

R2 - Connection bridge

☐ Connection 2.2

Only diesel engines

☐ Engine codes BXE, CAYB, CAYC, CGGA, CBDA, CBDB and CEGA



1.1.2 Relay on E-Box, MY 2011



Note

The number in brackets behind the part designation denotes the control number on the housing.

R1 - Motronic engine control module power supply relay -J271- (100)

- ☐ Connection 1.1
- ☐ Engine codes CBTA, CBUA, CBZA, CBZB, CAVD, CAXA and CGGA

R1 - Terminal 30 power supply relay -J317- (458)

- ☐ Connection 1.1
- ☐ Engine codes CLCA, CFHC, CFHB, CJAA, CAYB and CAYC

R1 - Simos control module power supply relay -J363- (458)

- □ Connection 1.1
- ☐ Engine codes BSE, BSF, CCSA and CCCA.

R2 - Secondary air pump relay -J299- (100)

- ☐ Connection 2.2
- ☐ Engine codes CBTA, CBUA, CCCA, BSE, BSF and CCSA

R2 - Auxiliary engine coolant pump relay -J496- (100)


- ☐ Connection 2.2
- ☐ Engine codes CAVD, CAXA, CBZA and CBZB.

R2 - Engine component current supply relay -J757- (100)

- ☐ Connection 2.2
- ☐ Engine code CCZA

R2 - Connection bridge

- ☐ Connection 2.2
- Only diesel engines
- ☐ Engine codes CJAA, CAYB, CAYC and CGGA



1.1.3 Relay on E-Box, through late 2011 MY forward



Note


The number in brackets behind the part designation denotes the control number on the housing.

R1 - Motronic engine control module power supply relay -J271- (100) Connection 1.1
☐ Engine codes CBTA, CBUA, CBZA, CBZB, CAVD, CAXA, CCZA and CGGA
R1 - Terminal 30 power supply relay -J317- (100) Connection 1.1
☐ Engine codes CLCA, CFHC, CFHB, CJAA, CAYB and CAYC
R1 - Simos control module power supply relay -J363- (458) Connection 1.1 Engine codes BSE, BSF, CCSA and CCCA
R2 - Secondary air pump relay -J299- (100) ☐ Connection 2.2 ☐ Engine codes CBTA, CBUA, CCCA, BSE, BSF and CCSA
R2 - Auxiliary engine coolant pump relay -J496- (100) ☐ Connection 2.2 ☐ Engine codes CAVD, CAXA, CBZA and CBZB.
R2 - Engine component current supply relay -J757- (100)

R2 - Connection bridge

Connection 2.2Engine code CCZA

- ☐ Connection A2
- Only diesel engines
- ☐ Engine codes CFHB, CFHC, CLCA, CJAA, CAYB, CAYC and CGGA



1.2 Relays on upper Vehicle Electrical Module

- ♦ ⇒ o1.2.1 n upper Vehicle Electrical Module -J519- , MY 2010", page 5
- ◆ ⇒ o1.2.2 n upper Vehicle Electrical Module -J519-, MY 2011", page 6
- ♦ ⇒ R1.2.3 elay on upper Vehicle Electrical Module -J519-, through late 2011 MY and forward", page 7


1.2.1 Relay on upper Vehicle Electrical Module -J519-, MY 2010



Note

-J4- is a mini-relay

- 1 Terminal 15 power supply relay -J329- (645)
 - ☐ Connection 1
- 2 Terminal 75 power supply relay 1 -J680- (644)
 - ☐ Connection 2
- 3 Dual tone horn relay -J4- (646)
 - ☐ Connection 3.1
- 3 Headlamp washer system relay -J39- (646)
 - ☐ Connection 3.2
- 4 Rear window defogger relay -J9- (645)
 - ☐ Connection 4
- 5 Terminal 50 power supply relay -J682- (645)
 - ☐ Connection 5




1.2.2 RelayRelay on upper Vehicle Electrical Module -J519-, MY 2011



Note

-J4- is a mini-relay

- 1 Terminal 15 power supply relay -J329- (645)
 - ☐ Connection 1
- 2 Terminal 75 power supply relay 1 -J680- (644)
 - ☐ Connection 2
- 3 Dual tone horn relay -J4- (646)
 - ☐ Connection 3.1
- 3 Headlamp washer system relay -J39- (646)
 - ☐ Connection 3.2
- 4 Rear window defogger relay -J9- (645)
 - ☐ Connection 4
- 5 Terminal 50 power supply relay -J682- (645)
 - ☐ Connection 5




1.2.3 Relay Relay on upper Vehicle Electrical Module -J519-, through late 2011 MY and forward



Note

-J4- is a mini-relay and is located on the relay connector panel

- 1 Terminal 15 power supply relay -J329- (645)
 - □ Connection 1
- 2 Terminal 50 power supply relay -J682- (645), Production Change
 - ☐ Connection 2
- 2 Starter relay 1 -J906- (645)
 - ☐ Connection 2
- 3 Dual tone horn relay -J4- (646)
 - ☐ Connection 3.1
- 3 Headlamp washer system relay -J39- (646)
 - ☐ Connection 3.2
- 4 Rear window defogger relay -J9- (645), Production Change
 - □ Connection 4
- 4 Terminal 50 power supply relay -J682- (645), Production Change
 - □ Connection 4
- 5 Terminal 75 power supply relay 1 -J680- (644)
 - ☐ Connection 5



1.3 Relays on lower Vehicle Electrical Module

- ◆ ⇒ b1.3.1 elow J519 module, MY 2010 ", page 8
- ♦ ⇒ b1.3.2 elow J519 module, MY 2011", page 10
- ♦ ⇒ b1.3.3 elow J519 module, through late 2011 MY forward", page 12

1.3.1 Relay below J519 module, MY 2010




Note

- ♦ The number in brackets behind the part designation denotes the control number on the housing.
- ♦ -J17,-J832 -J151 and -J757 are mini-relaysare mini-relays

1 - Fuel pump relay -J17- (646) ☐ Connection 1 1 - Fuel pump relay 2 -J49- (646) ☐ Connection 1 1 - Coolant circulation pump relay -J151- (646) □ Connection 1 ☐ Engine code CCZA 1 - Terminal 50 power supply relay -J682- (646) □ Connection 1 1 - Engine component current supply relay -J757- (646) ☐ Connection 1 2 - Fuel pump relay -J17- (646) ☐ Connection 2 2 - Fuel primer relay -J643- (646) ☐ Connection 2 3 - Low heat output relay -J359- (645) ☐ Connection 3 3 - Auxiliary heater operation relay -J485- (645) ☐ Connection 3 4 - Auxiliary fuel pump relay -J832- (645) □ Connection 4 5 - Fresh air blower relay -J13-

☐ Connection 5



1.3.2 Relay below J519 module, MY 2011




Note

- ♦ -J4-,-J17,-J49, -J643,J832 are mini-relays
- ♦ The number in brackets behind the part designation denotes the control number on the housing.

5 - High heat output relay -J360- (644)

☐ Connection 5

1 - Auxiliary fuel pump relay -J832- (646)
☐ Connection 1.1
☐ Engine codes CCZA, CFHB, CFHC and CLCA
1 - Coolant circulation pump relay -J151- (646)
☐ Connection 1.2
☐ Engine code CCZA,
1 - Starter relay 2 -J907- (507)
☐ Connection 1
2 - Fuel pump relay -J17- (646)
☐ Connection 2
Engine codes CGGA, BSE, BSF, CCSA, CBTA, CBUA, CCCA, CAYB, CAYC, CF and CLCA
2 - Fuel pump relay 2 -J49- (646)
☐ Connection 2.2
☐ Engine codes BSE, BSF, CAYB, CAYC, CCSA, CFHB, CFHC, CGGA and CLCA
2 - Fuel primer relay -J643- (646)
☐ Connection 2.2
☐ Engine codes CBTA, CBUA and CCCA
2 - Auxiliary fuel pump relay -J832- (646)
☐ Connection 2.2
□ Engine code CJAA
3 - Low heat output relay -J359- (645)
☐ Connection 3
3 - Fresh air blower relay -J13- (646)
□ Connection 3
4 - Auxiliary heater operation relay -J485- (645)
□ Connection 4



1.3.3 Relay below J519 module, through late 2011 MY forward




Note


☐ Connection 5

The number in brackets behind the part designation denotes the control number on the housing.

1 - Auxiliary fuel pump relay -J832- (646)
☐ Connection 1
☐ Engine codes CCZA, CFHB, CFHC and CLCA
1 - Starter relay 2 -J907- (507)
☐ Connection 1
1 - Terminal 50 power supply relay -J682- (507) Connection 1
2 - Fuel pump relay -J17- (646)
□ Connection 2.1
2 - Fuel pump relay 2 -J49- (646)
□ Connection 2.2
☐ Engine codes BSE, BSF, CAYB, CAYC, CCSA, CFHB, CFHC, CGGA and CLCA
2 - Fuel primer relay -J643- (646)
□ Connection 2.2
☐ Engine codes CBTA, CBUA, CCCA and CGGA.
3 - Low heat output relay -J359- (645)
☐ Connection 3
3 - Auxiliary heater operation relay -J485- (645)
☐ Connection 3
4 - Auxiliary fuel pump relay -J832- (645) ☐ Connection 4
5 - High heat output relay -J360- (644)
☐ Connection 5
5 - Fresh air blower relay -J13- (646)



Relays on Auxiliary Relay Carrier 1.4



2 - Automatic glow time control module -J179- 2- (457)