
DRIVER DOOR CONTROL SYSTEM HOW TO PROCEED WITH TROUBLESHOOTING

DI2BH-02

HINT:

This ECU is connected to the multiplex communication system. Therefore, be sure to check that there is no troubles in the multiplex communication system before performing the troubleshooting.



Step 6, 8 : Diagnostic steps permitting the use of the LEXUS hand–held tester.