
DI86Q=01

26. Cassette tape cannot be inserted.



NG

To the tape older.

Remove slack before using.

OK

Replace the radio receiver assembly.