
ENGINE (2JZ-GE)


HOW TO PROCEED WITH TROUBLESHOOTING

DI63H-0

When using hand-held tester, troubleshoot in accordance with the procedure on the following page.



When not using hand-held tester, troubleshoot in accordance with the procedure on the following page.



*: See Pub. No. RM588E on page DI-24