
RS07R-02



INSPECTION

1. VEHICLE NOT NVOLVED N COLLISION

Do@diagnostic@system@heck.

(SeepageDI-386)

2. VEHICLE INVOLVED IN COLLISION AND AIRBAGIS NOT DEPLOYED

Do@diagnosticsystemcheck.

(SeepageDI-386)

3. VEHICLE INVOLVED IN COLLISION AND AIRBAG IS DEPLOYED

Replace the airbag sensor assembly.