DI86J-01

19. Navigation screen cannot change to the hight mode color.

INSPECTION PROCEDURE	
1[Check[the[setting.[(Is[it[set[to[Day[Mode[in[screen[adjustment?)
	Yes □ Normal.
No	
2[Check[if[the[screen[]s[dimmed[at[hight.[(With[the[]ight[control[switch[ON,[do[all screens[except[the[havigation[screen[appear[]n[Night[Mode?)
	NG Go[to[step[5.
ОК	
3[]	Does[the[beep[sound[by[operating[switches[on[the[havigation[screen?
	OK Replace havigation ECU.
NG	
4[]	Check[]*AVC-LAN@communication@circuit*.[(See@page@DI-914)
	NG Replace or repair AVC-LAN circuit.
ОК	
Replace the navigation ECU.	

5 Check the multi display.

CHECK:

Check terminal TAIL.

<u>OK:</u>

TAIL: See "Multi Display" of "TERMINAL OF ECU".

OK Replace the multi display.

NG

Replace or repair wire harness.