ASSEMBLY
RSONK-02

INSPECTION1. Vehicles not involved in collision:

**INSPECT SUPPLEMENTAL RESTRAINT SYSTEM** 

Do@diagnostic[system@heck[Seepage[DI-369].

2. Vehicle involved in collision and airbag is not deployed:

**INSPECT SUPPLEMENTAL RESTRAINT SYSTEM** 

Do@diagnostic@system@heck@See@page@DI-369).

3. Vehicle involved in collision and airbag is deployed:

**INSPECT SUPPLEMENTAL RESTRAINT SYSTEM** 

Replace the side and curtain shield air bag sensor assembly See page RS-24).