


- M21 Rear Height Control Sensor Sub-Assembly LH
- Rear Hybrid Motor Control Inverter Assembly M34
- M35 Battery Voltage Sensor
- **HV Battery Junction Block Assembly** M37
- **Battery Cooling Blower Assembly** M38
- Inter Lock Switch M39
- M53 Rear Hybrid Motor Control Inverter Assembly
- M60 Canister Pump Module
- Rear Hybrid Motor Control Inverter Assembly S2
- **HV Battery Junction Block Assembly** S3
- **HV Battery Junction Block Assembly** S4
- U1 Rear Traction Transaxle with Motor Assembly
- V1 Rear Hybrid Motor Control Inverter Assembly
- HV Battery Junction Block Assembly V2
- V3 **HV Battery Junction Block Assembly**
- Rear Traction Transaxle with Motor Assembly i1
- Rear Hybrid Motor Control Inverter Assembly i2
- z5 HV Supply Battery Assembly, Battery Voltage Sensor
- HV Supply Battery Assembly , HV Battery Junction Block Assembly HV Supply Battery Assembly , Battery Voltage Sensor z6
- z9
- HV Supply Battery Assembly z18
- Hybrid Battery Terminal Block , HV Supply Battery Assembly z20
- Hybrid Battery Terminal Block, HV Supply Battery Assembly z21
- **HV Battery Junction Block Assembly** z22

Position of Parts in Body (From Dec. 2018 Production Nickel Metal Hybrid Battery)



Position of Parts in Body (From Dec. 2018 Production Nickel Metal Hybrid Battery)

