SA0SS-02

## **INSTALLATION**

Installation[]s[]n[]the[]reverse[]order[]of[]removal[[See[]page[\$A-94]).

AFTER[]NSTALLATION,[]CHECK[]ABS[\$PEED[\$ENSOR[\$IGNAL[]See[]page[]DI-210][]AND[]REAR[]WHEEL ALIGNMENT[[See[]page[]\$A-7])