Print


METER / GAUGE / DISPLAY HEADUP DISPLAY REMOVAL

PROCEDURE

■ 1.REMOVE UPPER INSTRUMENT PANEL ASSEMBLY

Click hereVehicle Interior>INTERIOR PANELS / TRIM>UPPER INSTRUMENT PANEL>REMOVAL

2.REMOVE METER MIRROR SUB-ASSEMBLY



Disconnect the connector.

- **b.** Disengage the clamp.
- **c.** Remove the 3 screws and meter mirror sub-assembly.

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.