
BO0V7-02



INSTALLATION

I. CLEAN AND SHAPE CONTACT SURFACE OF BODY

(a) Using a knife, cut away any rough areas on the body. HINT:

Leave as much of the adhesive on the body as possible.

(b) Clean the cutting surface of the adhesive with a piece of shop rag saturated in cleaner.

HINT:

Even if all the adhesive has been removed, clean the body.



(a) Remove the damaged stopper.

REPLACE STOPPER

(b) Cut off the old adhesive around the stoppers installation area.

NOTICE:

Be careful not to damage the body.


- (c) Clean the installation area.
- (d) Attach the stoppers to the glass with the ceramic notch on the glass aligned with the stoppers, as shown in the illustration.




- (a) Using a scraper, remove the adhesive sticking to the glass.
- (b) Clean the glass with cleaner.

NOTICE:

Do not touch the glass after cleaning it.






a a b b

b

a – a

b – b





U00040

4. INSTALL DAMS


Install the dams with double – stick tape as shown in the illustration.

A: 7.0 mm (0.276 in.) B: 10.1 mm (0.398 in.)

NOTICE:


Do not touch the glass face after cleaning it.





5. POSITION GLASS

- (a) Place the glass in the correct position.
- (b) Check that all contacting parts of the glass rim are perfectly even and do not make contact with the spacers.
- (c) Place reference marks between the glass and body.
- (d) Remove the glass.




6. CLEAN CONTACT SURFACE OF GLASS

Using a cleaner, clean the contact surface which is black-colored area around the entire glass rim.

NOTICE:

Do not touch the glass face after cleaning it.




7. COAT CONTACT SURFACE OF BODY WITH PRIMER

Using a brush, coat the contact surface of the body with Primer M.


NOTICE:

- Let the primer coating dry for 3 minutes or more.
- Do not coat Primer M to the adhesive.
- Do not keep any of the opened Primer M for later use.



8. COAT CONTACT SURFACE OF GLASS WITH PRIMER "G"

- (a) Using a brush or sponge, coat the edge of the glass and the contact surface with Primer G.
- (b) Before the primer dries, wipe it off with a clean shop rag. **NOTICE:**
 - Let the primer coating dry for 3 minutes or more.
- Do not keep any of the opened Primer G for later use.



9. APPLY ADHESIVE

(a) Cut off the tip of the cartridge nozzle.

Part No. 08850-00801 or equivalent


HINT:

After cutting off the tip, use all adhesive within the time described in the table below.

Temperature	Tackfree time
35°C(95°F)	15 minutes
20°C(68°F)	100 minutes
5°C(41°F)	8 hours

- (b) Load the cartridge into the sealer gun.
- (c) Coat the glass with adhesive as shown.

A: 12.5 mm (0.492 in.) B: 8.0 mm (0.315 in.)




10. INSTALL GLASS


HINT:

N08495

Confirm that the dam is attached to the body panel as shown in the illustration.



- (a) Position the glass so that the reference marks are lined up, and press in gently along the rim.
- (b) Using a spatula, apply adhesive on the glass rim.



- (c) Use a scraper to remove any excessive or protruding adhesive.
- (d) Hold the back window glass in place securely with a protective tape or equivalent until the adhesive hardenes.

NOTICE:


Take care not to drive the vehicle during the time described in the table below.

Temperature	Minimum time prior to driving the vehicle
35°C(95°F)	1.5 hours
20°C(68°F)	5 hours
5°C(41°F)	24 hours

11. INSPECT FOR LEAK AND REPAIR

- (a) Conduct a leak test after the hardening time has elapsed.
- (b) Seal any leak with sealant.


Part No. 08833-00030 or equivalent.



12. APPLY ADHESIVE TO MOULDING INSTALLATION AREA


Apply adhesive to the moulding installation area between the glass and the body.

Part No. 08833-00030 or equivalent.




13. INSTALL BACK WINDOW OUTSIDE LOWER MOULD-ING

Place the moulding onto the body and tap it by hand.




14. INSTALL BACK WINDOW OUTSIDE UPPER MOULD-ING

Place the moulding onto the body and tap it by hand.



15. INSTALL BACK WINDOW OUTSIDE MOULDING CLIP Using an air liveter with hose piece, strike livets into the body panel on stall the back window outside moulding clips to the body panel as shown in the illustration.




NOTICE:

If the livet is not positioned perpendicularly it will bend the mandrel. When the trigger is then pulled, it may damage SST.

16. INSTALL ROOF DRIP SIDE FINISH CENTER MOULDING


(See page BO-53)

17. INSTALL ROOM PARTITION TRIM Install he room partition rim with the sqlips.



18. INSTALL PACKAGE TRAY TRIM


Install package ray rim with he clips.



19. w/[High-mounted[\$top[Light: INSTALL[HIGH-MOUNTED[\$TOP[LIGHT]]]

Install@he@igh-mounted@stop@ight,@as@shown@h@he@llustration.

20. INSTALL SPEAKER GRILLE



21. INSTALL ROOF SIDE INNER GARNISH

Install@oof[\$ide@nner@arnish@o@he@body.

22. INSTALL THESE PARTS:

- (a) Rear seat side garnishes
- (b) Rear door opening trims
- (c) Rear door inside scuff plates
- 23. INSTALL REAR SEAT

(See page BO-120)

LEXUS[GS300] (RM588E)