

CAN COMMUNICATION SYSTEM PARTS LOCATION




*A	for LHD	-	-
*1	FORWARD RECOGNITION CAMERA	*2	INVERTER WITH CONVERTER ASSEMBLY

	(w/ Toyota Safety Sense)		
*3	BRAKE BOOSTER WITH MASTER CYLINDER ASSEMBLY	*4	ECM
*5	NO. 1 HEADLIGHT ECU SUB-ASSEMBLY LH	*6	MILLIMETER WAVE RADAR SENSOR ASSEMBLY (w/ Toyota Safety Sense)
*7	SWING GRILLE ACTUATOR ASSEMBLY (w/ Grille Shutter System)	*8	NO. 7 CAN JUNCTION CONNECTOR (w/o Occupant Classification System)
*9	BLIND SPOT MONITOR SENSOR LH (w/ Blind Spot Monitor System)	*10	REAR TELEVISION CAMERA ASSEMBLY (w/ Parking Assist Monitor System)




*A	for LHD	-	-
*1	COMBINATION METER MIRROR ECU (w/ Headup Display System)	*2	METER CIRCUIT PLATE
*3	CLEARANCE WARNING ECU ASSEMBLY (w/ Simple Intelligent Parking Assist System)	*4	DRIVING SUPPORT ECU ASSEMBLY (w/ Toyota Safety Sense)
*5	CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU)	*6	NAVIGATION RECEIVER ASSEMBLY (for Navigation Receiver Type)

			RADIO AND DISPLAY RECEIVER ASSEMBLY (for Radio and Display Type)
*7	OCCUPANT DETECTION ECU (w/ Occupant Classification System)	*8	TELEMATICS TRANSCEIVER (w/ Telematics Transceiver)
*9	AIRBAG ECU ASSEMBLY	*10	STEERING SENSOR
*11	POWER STEERING ECU ASSEMBLY	*12	DLC3
*13	MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU)	*14	CERTIFICATION ECU (SMART KEY ECU ASSEMBLY)
*a	Refer to Service Bulletin for the installation position of the part.	-	-




*A	for LHD	-	-
*1	NO. 2 CAN JUNCTION CONNECTOR	*2	NO. 1 CAN JUNCTION CONNECTOR
*3	AIR CONDITIONING AMPLIFIER ASSEMBLY	*4	NO. 3 CAN JUNCTION CONNECTOR
*5	NO. 4 CAN JUNCTION CONNECTOR	*6	HYBRID VEHICLE CONTROL ECU
*7	NO. 5 CAN JUNCTION CONNECTOR	-	-




*A	for RHD	-	-
*1	FORWARD RECOGNITION CAMERA (w/ Toyota Safety Sense)	*2	BRAKE BOOSTER WITH MASTER CYLINDER ASSEMBLY
*3	INVERTER WITH CONVERTER ASSEMBLY	*4	ECM
*5	NO. 1 HEADLIGHT ECU SUB-	*6	

	ASSEMBLY LH		MILLIMETER WAVE RADAR SENSOR ASSEMBLY (w/ Toyota Safety Sense)
*7	SWING GRILLE ACTUATOR ASSEMBLY (w/ Grille Shutter System)	*8	NO. 7 CAN JUNCTION CONNECTOR
*9	BLIND SPOT MONITOR SENSOR LH (w/ Blind Spot Monitor System)	*10	REAR TELEVISION CAMERA ASSEMBLY (w/ Parking Assist Monitor System)



*A	for RHD	-	-
*1	METER CIRCUIT PLATE	*2	COMBINATION METER MIRROR ECU (w/ Headup Display System)
*3	POWER STEERING ECU ASSEMBLY	*4	DLC3
*5	 NAVIGATION RECEIVER ASSEMBLY (for Navigation Receiver Type) RADIO AND DISPLAY RECEIVER ASSEMBLY (for Radio and Display Type) 	*6	AIRBAG ECU ASSEMBLY
*7	AIR CONDITIONING AMPLIFIER ASSEMBLY	*8	DRIVING SUPPORT ECU ASSEMBLY (w/ Toyota Safety Sense)
*9	MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU)	*10	CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU)
*11	CLEARANCE WARNING ECU ASSEMBLY (w/ Simple Intelligent Parking Assist System)	*12	CERTIFICATION ECU (SMART KEY ECU ASSEMBLY)
*a	Refer to Service Bulletin for the installation position of the part.	-	-



*A	for RHD	-	-
*1	HYBRID VEHICLE CONTROL ECU	*2	NO. 5 CAN JUNCTION CONNECTOR
*3	NO. 3 CAN JUNCTION CONNECTOR	*4	NO. 1 CAN JUNCTION CONNECTOR
*5	NO. 4 CAN JUNCTION CONNECTOR	*6	NO. 2 CAN JUNCTION CONNECTOR
*7	STEERING SENSOR	-	-