
LU0IL-04



INSPECTION

INSPECT OIL COOLER

Check the oil cooler for damage or clogging. If necessary, replace the oil cooler.