

REAR FLOOR SIDE REAR MEMBER (ASSY)








1. Replace the rear floor pan to quarter panel extension at the same time.

INSTALLATION



- 1. Temporarily install the new parts and measure each part in accordance with the body dimension diagram.
- 2. After welding the rear floor side rear member, install the quarter panel extension.
- 3. Attach the weld bolt to the center of the bearing surface.