LEXUS NAVIGATION SYSTEM (European Models Only)

■ DESCRIPTION

The Lexus navigation system displays the operating conditions of the air conditioner and of the audio system, trip information that is enclosed in the center cluster.

Furthermore, based on the GPS (Global Positioning System) voice navigation function, it analyzes the position of the vehicle and indicates that position on the map that is displayed on the screen, and provides voice instructions to guide the driver through the route to reach around the destination that has been selected. The basic construction and operation of this system are the same as in the LS400.

However, in the Lexus navigation system of the new GS300, the air conditioner temperature that is set for the driver, the temperature that is set for the front passenger, and the outside air temperature are displayed on the screen.

Listed below are the main functions of the Lexus Navigation system.

Function	Outline
Navigation Function	 Displays the present location and the direction of travel. Zooms in and out, rotates, and moves the map. Measures and corrects the present location. Sets and displays the route. Sets the destination. Zooms in at intersections and gives voice guidance. Displays the remaining distance to the destination and the expected time of arrival. Automatically resumes a route search. Searches for facilities in the vicinity of the present location. Registers, corrects, deletes, and displays Marked Points and Avoid Area. Enables or disables the display of the locus of travel. Corrects of coefficient of distance. Adjusts the voice guidance volume.
Audio Screen Display Function	Displays the operating condition of audio system.
Air Conditioner Screen Display Function	Displays the operating condition of the air conditioner.
On-Board Computer Screen Display Function	 Displays trip information/memory. Displays screen quality adjustment. Changes the units. Displays the possible continuous travel distance. Switches between day and night display.
On-Screen Display Function	Displays the operating condition of audio system.Displays the outside temperature.
Diagnosis Screen Display Function	Displays system diagnosis.Displays various types of coefficient settings.