## IN

## **TERMS**

## **ABBREVIATIONS USED IN THIS MANUAL**

| Abbreviations  | Meaning                      |
|----------------|------------------------------|
| A/T            | Automatic Transmission       |
| ATF            | Automatic Transmission Fluid |
| B <sub>0</sub> | Overdrive Brake              |
| B <sub>f</sub> | 3rd Coast Brake              |
| B <sub>2</sub> | 3rd Brake                    |
| B <sub>3</sub> | 2nd Brake                    |
| B <sub>4</sub> | 1st & Reverse Brake          |
| C <sub>0</sub> | Overdrive Clutch             |
| C <sub>1</sub> | Forward Clutch               |
| C <sub>2</sub> | Direct Clutch                |
| D              | Disc                         |
| F              | Flange                       |
| F <sub>0</sub> | Overdrive One-way Clutch     |
| F <sub>1</sub> | No.1 One way Clutch          |
| F <sub>2</sub> | No.2 One-way Clutch          |
| FIPG           | Formed in Place Gasket       |
| MP             | Multipurose                  |
| O/D            | Overdrive                    |
| Р              | Plate                        |
| S1             | Shift Solenoid Valve No.1    |
| \$2            | Shift Solenoid Valve No.2    |
| S3             | Shift Solenoid Valve No.3    |
| S4 .           | Shift Solenoid Valve No.4    |
| SSM            | Special Service Materials    |
| SST            | Special Service Tools        |
| w/             | with                         |
| w/o            | without                      |