BO0VD-02

REASSEMBLY

1. INSTALL BRACKETS

Install the 2 brackets with the 4 screws to the drive rails.

2. INSTALL CENTER HOUSING FRAME

Install the center housing frame with the 4 screws to the drive rails.

3. INSTALL REAR HOUSING FRAME

Install the rear housing frame with the 2 screws to the center housing frame.

4. INSTALL DRIVE CABLES


Slide the drive cables rearward to install them to the drive rails.

5. INSTALL SUNSHADE TRIM

Slide the sunshade trim forward to install it.

6. INSTALL DRIVE CABLE STOPPERS

Install the 2 drive cable stoppers with the 2 screws to the drive rails.




7. INSTALL SLIDING ROOF GUIDE BLOCKS

HINT:

Do the same for LH and RH.

- (a) Slide the sliding roof guide block rearward to install it to the drive rail.
- (b) Tighten the screw.



8. INSTALL SLIDING ROOF CASING


Install the sliding roof casing with the 12 screws.

9. INSTALL ROOF DRIP CHANNEL

Install the roof drip channel to the drive cables.

10. INSTALL CABLE GUIDE CASING

- (a) Slide the drive cables forward.
- (b) Insert the drive cables to the cable guide casing.
- (c) Install the 10 screws.




11. INSTALL DRIVE GEAR ASSEMBLY

(a) Using a screwdriver, remove the motor cover.

HINT:

Tape the screwdriver tip before use.

- (b) Turn the drive shaft with screwdriver to align the housing with gear point mark as shown in the illustration.
- (c) Install the motor cover.
- (d) Install the map lamp bracket with the 2 screws to the gear assembly.
- (e) Install the drive gear assembly with the 2 bolts.



12. INSTALL WIND DEFLECTOR PANEL

(a) Using a screwdriver, slide the drive cable rearward. HINT:

Tape the screwdriver tip before use.

(b) Install the wind deflector panel with the 4 screws.