DI29X-05

Luggage compartment door lock and unlock switch circuit

CIRCUIT DESCRIPTION

The luggage compartment door lock and unlock switch goes on when the luggage compartment door key cylinder is turned to the unlock side with the key.

WIRING DIAGRAM

