


BODY PANEL SEALING AREAS


HINT:


- 1. Prior to applying body sealer, clean the area with a rag soaked in a grease, wax and silicone remover.
- 2. If weld-through primer was used, first wipe off any excess and coat with anti-corrosion primer before applying body sealer.
- 3. Wipe off excess body sealer with a rag soaked in a grease, wax and silicone remover.
- 4. If body sealer is damaged by peeling, cracks, etc., be sure to repair as necessary.
















Flat Surfacing



Flat Surfacing



Flat Surfacing

