Position of Parts in Engine Compartment

[LHD: Engine 1]

- *1 : HID Type *2 : Except HID Type
- *3: w/ Headlight Beam Level Control (Automatic)
- *4: w/ Headlight Beam Level Control (Manual)

