## 2. System Operation

## General

• The ECUs that pertain to the body electrical system perform the functions and system controls described in the following chart.

: Added

ECU		Function and System Control
Bus centered on Body ECU	Body ECU	Door Lock Control
		Wireless Door Lock Remote Control System
		• Interior Light Control
		Exterior Light Control
		• Theft Deterrent System
		• Customize
	Sub-Body ECU	Rear Wiper Control
		Lounge Light Control
		Side-step Light Control
		Rear Light Failure Control
		Customize
	Wiper ECU	Wiper and Washer Control
	1	Customize
	Rain Sensor	Raindrop Sensing Function
		Customize
	Theft Deterrent ECU	Theft Deterrent System
		Customize
	Power Seat ECU	Power Seat Function
		Memory System
		Customize
	Tilt and Telescopic ECU	Tilt and Telescopic Control
		Customize
	Remote Control Mirror ECU	Outer Side Rear View Mirror Control
		Customize
	Moon Roof Control ECU	Moon Roof Control
		Customize
	Driver Door ECU	Power Window System Control
		Customize
Bus centered on Engine ECU	Meter ECU	Combination Meter Display (gauge, indicator, warning)
		Buzzer System (Key Reminder, Seat Belt Reminder, VSC)
		Warning)
	Engine ECU	Engine Control
		A/T Control
		Cruise Control System
	A/C ECU*	Air Conditioner Control
	Gateway ECU*	Gateway Function
	Multi Display*	Navigation System Operation Function
		Air Conditioner System Operation Function
		Trip Information Function
	Navigation ECU*	Navigation System Control
		- •

<sup>\*:</sup> with Multi Display model (only for Australia model)