DI1SR-03

DTC	B1232 / 32	Jam protection pulse switch circuit on driver door
DTC	B1234 / 34	Jam protection pulse switch circuit on passenger door
DTC	B1236 / 36	Jam protection pulse switch circuit on rear right door
DTC	B1238 / 38	Jam protection pulse switch circuit on rear left door

CIRCUIT DESCRIPTION

These DTCs are output when a malfunction of pulse switch within power window motor is detected.

DTC No.	DTC Detecting Condition	Trouble Area
B1232/32		Jam protection pulse switch Wireharness
B1234/34	No change in pulse switch more than 2.0 seconds even if	
B1236/36	opening glass down when limit switch is OFF (window glass is fully closed).	
B1238/38	(a g.a,,	

HINT:

Please refer to power window control system of BE section for switch inspection, and to each door system of DI section for wireharness inspection.