## **CIRCUIT INSPECTION**

DI86C-01

## **Power source circuit**

## **CIRCUIT DESCRIPTION**

This circuit provides power to operate the body ECU No. 1.

## **WIRING DIAGRAM**



