DI2AF-05

CIRCUIT INSPECTION

Power source circuit

CIRCUIT DESCRIPTION

This circuit provides power to operate the Body ECU No. 2.

WIRING DIAGRAM

