

FI0WK-01



## INSTALLATION

- 1. INSTALL THROTTLE BODY
- (a) Connect the water bypass hose to the manifold thermostat on the throttle body.



(b) Install a new gasket and the throttle body with the 2 bolts and 2 nuts.

Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)

- (c) Connect the water bypass hose to the No.5 water bypass pipe on the throttle body.
- (d) Connect the connector.
- 2. INSTALL INTAKE AIR CONNECTOR PIPE
- 3. FILL[WITH]ENGINE[COOLANT][See[page[CO-2)]
- 4. START ENGINE AND CHECK FOR ENGINE COOLANT LEAKS
- 5. INSTALL V-BANK COVER