

- M35 **Battery Voltage Sensor**
- **HV Battery Junction Block Assembly** M37
- **Battery Cooling Blower Assembly** M38
- Inter Lock Switch M39
- Canister Pump Module M60
- **HV Battery Junction Block Assembly** S3
- HV Battery Junction Block Assembly S4
- HV Supply Battery Assembly , Battery Voltage Sensor z5
- HV Supply Battery Assembly , HV Battery Junction Block Assembly HV Supply Battery Assembly , Battery Voltage Sensor z6
- z9
- **HV Supply Battery Assembly** z18
- Hybrid Battery Terminal Block , HV Supply Battery Assembly Hybrid Battery Terminal Block , HV Supply Battery Assembly z20
- z21
- HV Battery Junction Block Assembly z22

Position of Parts in Body (Before Dec. 2018 Production Nickel Metal Hybrid Battery)

