




- M6 Front Door Courtesy Light Switch Assembly LH
- M7 Front Seat Outer Belt Assembly LH
- M8 Side Airbag Sensor Assembly LH
- M9 No. 2 Indoor Electrical Key Antenna Assembly
- M10 Fuel Suction Tube with Pump & Gage Assembly
- M11 Rear Airbag Sensor LH
- M12 Rear Door Courtesy Light Switch Assembly LH
- M14 Tire Pressure Warning Antenna and Receiver (Electrical Key & Tire Pressure Monitoring System Receiver Assembly)
- M16 Curtain Shield Airbag Assembly LH
- M17 Curtain Shield Airbag Assembly RH
- M22 Radio Setting Condenser
- M31 No. 3 Indoor Electrical Key Antenna Assembly
- M32 Fuel Lid Lock with Motor Assembly
- M33 No. 1 Luggage Compartment Light Assembly
- M42 Rear Combination Light Assembly RH
- M43 Rear Combination Light Assembly LH
- M48 Front Door Courtesy Light Switch Assembly RH
- M49 Front Seat Outer Belt Assembly RH
- M50 Side Airbag Sensor Assembly RH
- M51 Rear Airbag Sensor RH
- M52 Rear Door Courtesy Light Switch Assembly RH
- M62 Vapor Pressure Sensor
- M73 No. 6 CAN Junction Connector
- M75 No. 15 Junction Connector
- M76 No. 16 Junction Connector
- M78 No. 7 CAN Junction Connector
- M87 Rear Seat Inner Belt Assembly RH
- M88 Rear Seat Inner Belt with Center Assembly LH
- M89 Rear Seat Inner Belt with Center Assembly LH
- M93 Purge Flow Switching Valve
- M96 No. 23 Junction Connector
- M97 Rear Speed Sensor LH
- M98 Rear Speed Sensor RH
- M99 Vapor Pressure Sensor
- M102 Vehicle Approaching Speaker Controller
- M103 No. 2 Side Airbag Sensor Assembly LH
- M104 Rear Seat Airbag Assembly RH
- M105 Rear Seat Airbag Assembly LH
- M106 No. 2 Side Airbag Sensor Assembly RH
- M107 No. 7 CAN Junction Connector



90980-12699



Position of Parts in Body (From Dec. 2018 Production)



90980-12C68