This document is uncontrolled when printed.



DOCUMENT GSM-AUS-CPL.006

DOCUMENT TITLE AIR LAW 1 (AUS)

CHAPTER 11 – RADIO FAILURE PROCEDURE

Version 2.2 May 2017

This is a controlled document. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior permission, in writing, from the Chief Executive Officer of Flight Training Adelaide.

CHAPTER 11 RADIO FAILURE PROCEDURE



AIR LAW 1 (AUS)

CONTENTS	PAGE
RADIO FAILURE	
11.1 INITIAL ACTIONS	
11.2 RADIO FAILURE IN THE TRAINING AREA	

CHAPTER 11
RADIO FAILURE PROCEDURE



AIR LAW 1 (AUS)


RADIO FAILURE

11.1 Initial Actions



- 1. Remain in VMC.
- 2. Check:
 - i. Radio switch 'ON'.
 - ii. Frequency selected correctly.
 - iii. Headset plugged in firmly.
 - iv. Radio volume turned up.
- 3. Make normal radio calls and prefix calls with "transmitting blind".
- 4. Select (Squawk) Transponder code 7600. Adelaide Approach should see your "Squawk" and will notify Parafield tower that an aircraft is inbound to Parafield with a radio failure.

Note: they will not know your call sign.



In the event of radio failure, squawk 7600 on the transponder

- 5. Tune ADF and listen to ATIS for broadcast instructions.
- If on a navigation OCTA (outside controlled airspace) land at the
 nearest suitable non CTAF certified, registered or military aerodrome
 (a Common Traffic Advisory Frequency aerodrome where carriage and
 use of radio is required) and report your arrival by telephone to an ATS
 unit.

CHAPTER 11 RADIO FAILURE PROCEDURE



AIR LAW 1 (AUS)

11.2 Radio Failure in the Training Area

- 1. Check:
 - i. Radio switch 'ON'.
 - ii. Frequency selected correctly.
 - iii. Headset plugged in firmly.
 - iv. Radio volume turned up.
- 2. Tune ADF and listen to ATIS.
- 3. Descend to 1500 FT by Outer Harbour and maintain height, give inbound call, prefix all radio calls by "transmitting blind" (...YNC, transmitting blind).
- 4. Arrive overhead aerodrome at 1500 FT.
- 5. Find out which runway is in use. (Check windsock (wind indicator) and other aircraft in the circuit pattern).
- 6. Keep a good lookout for other aircraft.
- 7. Descend to circuit height to enter at downwind entry point.
- 8. Give a downwind radio call (...YNC, transmitting blind).
- 9. On final approach, look out for a light signal from the tower.
 - i. Steady Green clear to land.
 - ii. Steady Red go round make another circuit.



