This document is uncontrolled when printed.



DOCUMENT GSM-EL-PS1.054

DOCUMENT TITLE PRE-SOLO SELF STUDY 1

CHAPTER 18 – GLOSSARY

Version 3.5 January 2018

This is a controlled document. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior permission, in writing, from the Chief Executive Officer of Flight Training Adelaide.



CONTENTS	PAGE
GLOSSARY: CIRCUIT AND RADIO TELEPH	ONY VOCABULARY 3



PRE-SOLO SELF STUDY 1

GLOSSARY: CIRCUIT AND RADIO TELEPHONY VOCABULARY

Word	Meaning	Example
Abeam	In line with your wing tip. In your 3 o'clock or 9 o'clock position.	TGM, report abeam Bolivar Strobe. Wilco, TGM
Acknowledge	Let me know you have heard and understood my instruction	You must acknowledge radio calls made to your aircraft.
Active runway	Any runway being used for take-off or landing.	
Adjacent to	Next to.	SEA, just caution, personnel operating adjacent to the taxiway.
Affirm	Yes	TGY, confirm you have the Cherokee in sight? TGY, affirm, traffic in sight
Aircraft 'inside you'	An aircraft has turned, and it is now between you and the runway.	XYM, caution, there's a Grob inside you on base leg. Report sighting.
Aircraft 'High'	Another aircraft is above your level.	TGZ, you are number two to a Tobago, inbound from the Dam Wall, currently high in your 12 o'clock.
Aircraft 'Low'	Another aircraft is below your level.	XYG, make straight -in approach, runway 21 left. You will be number one to a Grob on late downwind, low in your 10 o'clock.
Amended	Clearances are often changed. The controller may use this word.	WZA, amended clearance, track via Port Adelaide to Adelaide
Approved / not approved	Allowed / not allowed.	WZA, asymmetric circuits approved. TGM, glide approach not approved. Follow the Grob ahead upwind.
Apron	The hard (paved) area surrounding the control tower and the hangars, used for taxiing and parking of aircraft.	
Arrivals	Aircraft inbound to Parafield.	ATIS: - "Arrivals and departures West use runway 21 right, Tower frequency 118.7."
Asymmetric circuits	Circuits practiced by multi- engined aircraft, with one engine simulated inoperative.	BTO, asymmetric circuits not available on that runway."
Auto-rotations	A helicopter making an approach to land, after a simulated (or real) engine failure.	* When a helicopter practices auto-rotations, it descends very quickly.



Word	Meaning	Example
Backtrack	To do a 180° turn on the runway, and taxi back along the runway towards the threshold.	TGM, backtrack approved. Report ready.
Balloon	A term used to describe when the pilot flares too quickly, and the aircraft gains height above the runway.	Instructor: "Frank, you will have to learn the correct actions to recover the aircraft from a balloon."
Bird-strike	A bird-strike occurs when an aircraft hits a bird or birds.	
Bitumen	Surfaces of runways sealed with a black tar material. Also called asphalt.	
Blowout	A punctured tyre, which will deflate quickly.	The student landed with his feet on the brakes, and caused a tyre to blowout. He subsequently lost directional control of the aircraft.
Boggy area	An area of soft and or wet ground If you taxi over it you might get the landing gear stuck.	
Bounce	On landing, the aircraft hits the ground, and before gaining height above the runway. Unless the pilot corrects, a series of larger and larger bounces may result.	
Boundary	The line between two areas.	The Little Para River is the boundary between the Parafield Control Zone, and the Edinburgh Control Zone.
Break Break	Indicates the separation between messages to 2 different aircraft	XYB, hold position. Break break YTV, go ahead again your call.
Cable (Tie-down cable)	A length of strong wire for securing the aircraft when they are parked.	
Cancel	Annul the previously transmitted clearance	WZA, cancel the landing clearance, continue approach.
Centreline	The white broken line down the middle of a sealed runway	
Clearance	A set of instructions	
Cleared	Authorised to proceed under the conditions specified.	XFG, cleared for take off
Close	A 'close' circuit is one which is nearer to the runway than normal.	TGE, your circuit is too close. Request you widen out your circuit?



Word	Meaning	Example
Coastline	Where the land meets the sea.	
Collide / collision	To hit something.	If you do not watch your wingtips when you are taxiing, you may collide with another parked aircraft. You will have a collision.
Cone markers	Small cones used to mark surfaces around the airport. They are often used to mark obstacles or unserviceable areas.	
Confirm	To request an answer yes or no to a question. To check that information has been received or understood correctly. *Never answer a question with your callsign only.	XYD, confirm you have the Grob in your 2 o'clock in sight? XYD, affirm, traffic in sight. or XYD, negative contact
Contact	To call someone on the radio.	LQC, contact the Tower now on 124.6
Control Tower	A tall building from where the Controllers watch the movements of aircraft, and give instructions to the pilots.	
Correction	An error has been made in this transmission. The correct version is	XTV, correction XTY, clear for take off
Crosswind circuits	Take-offs and landings which are practiced not into wind. They are often practiced on a different runway.	All Stations, there are crosswind circuits starting on runway 26 left.
Crosswind component	The amount of wind blowing across the runway.	XYF, crosswind 10-15 knots.
Dam Wall	An inbound reporting point, north east of Parafield.	HYA, you're number two. Follow a Cherokee, inbound from the Dam Wall, currently in your 10 o'clock.
Departures	Aircraft flying away from Parafield.	ATIS: "Arrivals and departures east use"
Delay	To wait for a short time.	TGE, ready, request a 10 second delay.
Do not delay	Don't wait	XYA, do not delay, clear for takeoff.
Disabled aircraft	An aircraft which has been damaged, and cannot be taxied.	The Tobago was forced to go around, because there was a disabled aircraft on the runway.



Word	Meaning	Example
Displaced	The first part of the runway cannot	·
threshold	be used, and the threshold has	
	been moved further along the	Zinin/
	runway.	
Dust Devil	Dangerous revolving air masses,	The pilot decided to go around, rather than
	occurring in the summer months.	land when a dust devil was about to cross the
_		runway.
Duty runway	The runway nominated for use on	
	the ATIS. Where it is possible, the	
	'Duty runway' is the most into wind	
Early turn	runway. After doing a go-round, an aircraft	WZA early right turn available, advise.
Larry turn	may be allowed to turn early and	WZA early right turn available, advise.
	join the circuit at the mid-	
	downwind position.	
Expedite	To do something faster than usual	TGK, expedite descent to circuit altitude.
Extend	To make longer	HGK, extend your downwind leg until advised"
Field	The aerodrome	YTG, overfly the field for a left downwind
		runway 03 L
Flapless	To make an approach to land	If you have an electrical failure in the Grob or
approach	without the use of the flaps.	the TB10, you will have to do a flapless
		approach.
Flight strip	The area inside the gable markers	TGT, confirm clear of the flight strip
	of a runway.	
Flock	A large number of birds	TO 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Full-stop	The aircraft will land, and turn off	TGA, confirm the preceding aircraft is making a
landing	onto a taxiway.	full-stop landing?
Gable markers	Long white, yellow or blue markers.	
	White gable markers are along the	
	sides of the runways.	
	Yellow markers are along the	
	taxiways.	
	Blue markers are along the sides	
	of the areas used for helicopter	
	practice.	
General	A Tower transmission to warn all	"All stations, There is a dust devil just crossing
Broadcast	aircraft of a hazard in the circuit	the upwind threshold of runway 03 right."
	area.	
	* Do not answer a General	
	Broadcast.	



Word	Meaning	Example
Gepps Cross	Gepps Cross is the	
	intersection of five roads,	
	about 4 miles south of	
	Parafield. It used to be	
	requested as a reporting	
	point, because it lies on the	
	boundary between the	
	Parafield and Adelaide	
	Control zones. It is no longer	
	shown on the VTC and has	
	been replaced by the	
	Velodrome.	
Glide Approach	An approach to land on the	XYC, glide approach approved.
	runway with the throttle fully	
	closed. (to simulate engine	
	failure)	
Hangar	A large building for the	
	storing and maintenance of	
	aircraft	
Hazards	Dangers.	Dust devils and flocks of birds, are two
		common hazards in the Parafield circuit.
Helipad	The place a helicopter lands	
	and takes off a rotary wing.	
Holding Point	A point (marked with lines	
	painted across the taxiway),	
	which an aircraft cannot taxi	
	past without permission from	
	the controller.	
Hold position	Do not move!	THA, hold position, Tobago on final.
Identify	To see and recognise the	PLW, traffic for you to sight is a Cessna
	traffic the Controller is telling	210, inbound from the Dam Wall.
	you about.	
Immediate	The controller uses the word	MHO, line up and be ready immediate. (Be
	immediate(ly) when he wants	ready to take off quickly when given your
	you to act faster than usual.	take off clearance)
Inbound	Inbound traffic is traffic flying	XYB, follow the Cherokee inbound from the
	towards Parafield.	Dam wall, currently in your 11 o'clock.
Increase speed	Fly faster than usual	TGE, increase speed, the Lear Jet is about
		to join the circuit
Inside	On a closer (smaller)	YHA, caution, traffic inside you is a Grob.
	circuit.	Have you got him in sight?



Word	Meaning	Example
I say again	I am repeating what I just said for emphasis.	XYC, I say again, make a right turn!
Keep your speed up	Don't slow down.	YHH, keep your speed up, I've got the jet inbound from Velodrome behind you!
Late downwind	A position along the downwind leg, approaching the base turning point.	TGT, follow the Grob ahead on late downwind.
Low level circuits	Circuits practiced on runway 21 right, or 03 Left, which must be done at 500 feet, inside the airport boundary on the downwind leg.	HYF, join circuit on a right base, runway 21 right and report on base. You will be following the Cap-10 on low-level circuits, currently in your 3 o'clock low.
Maintain	To keep doing the same thing.	XYB, maintain runway heading until advised.
Mid-downwind	A position half way along the downwind leg.	TGM, make an early right turn to join mid-downwind.
Monitor	Listen out on this frequency	XYF, monitor Adelaide Centre 130.45
Negative	No!	TGT, have you the Cessna sighted? TGT, negative, traffic not sighted.
Negative ATIS	There is no ATIS on 120.9 when you listen. Usually this means that the Controller is making a new ATIS.	Parafield Tower, Grob, TGM, Outer Harbour 1500, inbound with negative ATIS.
Oblique- downwind -Base	A downwind / base leg at an angle.	When we are inbound from the training area to land on runway 21 right, we fly an oblique downwind leg, and join the circuit on a right base.
Ops (operations) normal	Everything is OK; you don't have any aircraft problems.	YTO, confirm ops normal
Orbit	A 360° turn while maintaining your present height.	TGZ, make one right hand orbit in your present position.
Outbound	Traffic which is flying away from Parafield is outbound.	WZA, the traffic ahead of you is outbound for Port Adelaide.
Outside	Further from the runway than you. Flying a larger circuit.	TGE, have you the traffic outside you in your 3 o'clock sighted?
Overfly	Fly overhead and past a point	YTH, overfly the field



Word	Meaning	Example
Overshoot	Go round! To conduct a 'missed approach.' To fly through the extended centre-line of the runway, when you are turning onto final.	Ario that is the third time you have overshot the turn onto final, which is a very dangerous thing to do!
Pigeons	Birds that fly in large 'flocks' around the aerodrome.	"All Stations, there is a large flock of pigeons on the approach to runway 21 left."
Port Adelaide	A common tracking point when flying between Parafield and Adelaide airports.	FRG, amended clearance, track Adelaide via Port Adelaide, 1500.
Preceding aircraft	The aircraft in front of you.	XYH, the preceding aircraft will be making a full-stop.
Pull your speed in / back	Reduce speed / Fly slower than usual.	YHD, can you pull your speed back a little, I'm trying to get another aircraft in ahead of you.
Ranges	The hills east of Parafield	
Readable/ unreadable	Can / cannot be understood. "How do you read? Reading you 3 or readability 3	TGJ, your transmissions are unreadable. Try the other radio!
Request	Ask	XYA, request glide approach.
Request best speed	Fly faster than usual	TGE, request best speed, the Lear Jet is about to join the circuit
Roger	I have received all of your last transmission	
Report	Pass requested information	XYA, report your heading
Run-up bay	An area used to park aircraft, while they are doing pre-take off and engine checks.	
Say again	Repeat all or the following part of your transmission	
Sequence (Circuit sequence)	The landing order.	TGK, you'll be number two in the sequence now, following a Tobago joining mid-downwind.
Sight	To see.	TLF, report sighting the Diamond in your 10 o'clock.



Word Meaning Example Simultaneous Contra circuits Circuits in opposite directions, taking place at the same time on parallel runways. Parafield airport has simultaneous contra-circuits. Standby Wait I will call you. Stop and go landing on the runway. It will then A clearance to make a stop and landing automatically clears the stop and landing automati	go
circuits directions, taking place at the same time on parallel runways. Standby Wait I will call you. Stop and go landing The aircraft will land and stop on the runway. It will then Contra-circuits. A clearance to make a stop and landing automatically clears the	go
same time on parallel runways. Standby Wait I will call you. Stop and go landing The aircraft will land and stop on the runway. It will then landing automatically clears the	•
runways. Standby Wait I will call you. Stop and go landing The aircraft will land and stop on the runway. It will then Inding automatically clears the	•
Standby Wait I will call you. Stop and go landing The aircraft will land and stop on the runway. It will then A clearance to make a stop and landing automatically clears the	•
Stop and go landing The aircraft will land and stop on the runway. It will then A clearance to make a stop and landing automatically clears the	•
on the runway. It will then landing automatically clears the	•
	aircraft
	· · ·
take off from its present to takeoff again.	
position on the runway.	
Tarmac Another word for apron	
Taxing line A line painted on the ground	
for aircraft to follow when	
taxiing.	
Tighten your circuit up Do a smaller (closer) circuit. TGT, your circuits are too wide.	Request
a bit. you tighten up your circuits?	
Touch and go landing The aircraft will land, and XYD, cleared touch and go.	
then accelerate and take off	
again.	
Tracking Using a navigational aid to fly	
from one place to another	
Traffic Other aircraft. YHD, caution, there is traffic	starting
crosswinds on runway 26.	
Undershoot The area of a runway beyond	
the threshold that you fly over	
on landing	
Unservicable runway	
white cross, painted on the	
surface of the runway.	
Vacate To leave LAB, vacate the runway via the r	ext
taxiway left	



Word	Meaning	Example
Verify	Check and confirm	
Westbound	Travelling to the west	
Widen out	To fly so that your downwind leg is further from the runway	TGZ, can you widen out a bit. Your circuits are too close
Windsock	A device placed near the runways, made from light material that blows in the wind, giving an indication of the wind speed and direction.	
Wilco	I understand your message and will comply with it.	
Works in Progress (WIP)	Maintenance or construction of runways, taxiways or any other part of the airfield.	POQ, caution, runway 21 has a displaced threshold due works in progress. (WIP on NOTAMS)
You can roll through	You do not have to exit the runway via the next taxiway. You can continue to roll along the runway, and take the last taxiway if you want to. This saves taxiing time, particularly on runway 03 left.	You cannot roll through unless you have permission from the Controller.