## **BEFORE START**

DLI OIL	JIANI
Security Cable	
Pitot/Stall cover	REMOVED
Maint. Release	CHECKED & ON BOARD
Flight Manual	ON BOARD
Departure Brief	GIVEN
Approach Brief	
Passenger Brief	IF REQUIRED
Rear Door	
Front canopy	SECURE/COOLING GAP
Rudder Pedals	
Fuel Selector	
Mixture	CHECKED & ICO
Pitch	CHECKED & FULL FINE
Throttle	CHECKED & IDLE
Parking Brake	SET
Alternate Air	
Alternate Static`	CLOSED
ESS BUS Switch	OFF
Avionics Master	
Master Switch BAT/ALT	ON
Magnetos	OFF
Fuel Pump	OFF
Pitot Heat	OFF
Flaps	UP
Circuit Breakers	IN
ELT	ARMED
CO Detector	TESTED
Emergency Switch	OFF & GUARDED
Position Lights	ON
Flood, Instrument Lights	AS REQUIRED
G1000 Database	ACKNOWLEDGED
FMS Setup-AUX 4	COMPLETED
PFD/MFD	BACKUP MODE
MFD	ENGINE/SYSTEMS
Fuel Quantity	CHECKED AND RESET
Strobe Lights	ON, AS REQUIRED
Area	CLEAR

## 

#### **ENGINE START**

## START ENGINE, THEN:

Oil Pressure	CHECKED
Ammeter	CHECKED
Annunciation Panel	CHECKED
Fuel Pump	OFF
Fuel Pressure	CHECKED

## **AFTER START**

Avionics Master	ON
Pitot Heat	CHECKED
Radios, Nav Aids	SET, SET & IDENTIFIED
ATIS	RECIEVED
Altimeters (2)	QNH SET, CHECKED
PFD/MFD	NORMAL MODE
ANN TEST(Aux 5)	CHECKED
Flight Plan	ACTIVATED
Standby AI	CHECKED
Taxi Light	ON

#### **TAXI**

Brakes	CHECKED
Rudder	CHECKED
Flight Instruments	CHECKED
Nav Aids	TRACKING

## **RUN UP**

*Oil Temperature	ABOVE 100°F*
*Fuel	Change Tanks*
	CYCLED 3 TIMES
Magnetos	CHECKED
	CHECKED
* Indicates a proce	edure within the checklist

# 

## **BEFORE TAKE-OFF**

Trim	CHECKED & SET
Fuel Selector	ON
Mixture	RICH
Pitch	FULL FINE
Magnetos	BOTH
Fuel Pump	ON
Controls	CHECKED
Flight Instruments	SET & CHECKED
Engine Parameters	IN LIMITS
Altimeters (2)	QNH SET & CHECKED
Flaps	SET
Circuit Breakers	
Harnesses	SECURE
Clearance	RECEIVED
Transponder	SET
EFIS	SET FOR DEP, BRIEFED

## 

TOSB	GIVEN
1 O D	CIVEIN

#### 

#### **HOLDING POINT**

Rear Door	SECURE
Front Canopy	SECURE
Door Annunciations	OUT



# ENTERING RWY

Departure Instructions	ACKNOWLEDGED
Pitot Heat	ON / As Required
Strobe Lights	ON
Landing Light	

# TAKE-OFF

Power	MAX
T's and P's	GREEN
Airspeed	INCREASING

## AFTER TAKE-OFF

Brakes	APPLIED
Flaps	UP
Climb Power	SET
Landing Light	OFF

#### **CLIMB**

Manifold Pressure	CHECKED
OAT	CHECKED
Annunciations	CHECKED
T's and P's	
Altimetry	

# **CRUISE**

Compass & HSI	ALIGNED
	COMPLETE / NOT REQUIRED
	GREEN
Altimetry	CHECKED
Radios	SET
Orientation	CHECKED
Fuel	SUFFICENT
Fuel pumps	OFF

## PRE MANOEUVRE

Height	RECOVER BY 3000' AGL
	CHECKED
Security	CHECKED
	GREEN
=	CHECKED
Lookout	COMPLETED

# DESCENT

Compass & HSI	ALIGNED
Altimeters (2)	QNH SET & CHECKED
Auto Pilot BARO QNH	QNH SET & CHECKED
Aids	SET & IDENTIFIED
Mixture	RICH
Radios	SET
Approach Brief	GIVEN

## **BEFORE LANDING**

BEI ONE EANDING	
Brakes	CHECKED
Park Brake	OFF
Gear	FIXED
Mixture	RICH
Fuel Pumps	ON
Fuel Tank	FULLEST
Fuel Quantity	SUFFICIENT
Landing Light	ON
Harnesses	SECURE

# LANDING

Park Brake	RELEASE
Gear	FIXED
Pitch	FULL FINE
Flaps	SET
Landing Clearance	
Runway	

#### 

## AFTER LANDING

Pitot Heat	OFF
Fuel Pump	OFF
Flaps	UP
Strobe Lights	ON, AS REQUIRED
Landing Light	OFF

# SHUTDOWN

Park Brake	SET
Throttles	1000RPM
Engine/System Page	TIME/FUEL CHECKED
Avionics Master	OFF
Magnetos	CHECKED
Mixture	ICO
Magnetos	OFF
Start Key	
Strobe Lights	OFF
Position Lights	OFF
Taxi Light	OFF
Electric Master	OFF
Interior/Instrument Lights	CHECKED OFF

POST FLIGHT DUTIES		
Control Lock	FITTED	
Doors	LATCHED	
Pitot Cover	ON	
Security Cable	FITTED	
After Flight Inspection	COMPLETED	