


EasyTouch Portion Control Keypad Programming / Operating Instructions

The EasyTouch Portion Control Keypad for the LEV valve operates at the touch of your finger. The control has 5 actuators (selections): Kid, Small; Medium; Large; Pour/Cancel.

If you are unsure how to operate or program this control, please call 1-800-817-2653, Ext 2.



Portioned Drink Dispense

- 1. Fill cup with appropriate amount of ice
- 2. Place cup under nozzle
- 3. Touch appropriate size button
 - LED lights during pour




Programming

- 1 To enter programming mode, touch small and extra large sizes at the same time.
 - Hold for 2 seconds until LED lights
- 2 To set portion, place cup under nozzle and touch corresponding portion button until desired liquid level obtained (Small button highlighted)

NOTE: If LED goes out during programming, all data is retained; however, you must re-enter programming mode to set any remaining sizes.

- 3 To exit programming, touch pour/cancel.
 - LED turns off



NOTES: 1. Programming data will also be saved if the keypad is in programming mode and not touched for 60 seconds. 2. Lock out will occur if button is pressed for more than 15 seconds. Power unit off and on to clear the lockout.

- If you touch a size button for more than 15 seconds, that size will lock out. If you touch the pour/cancel

button for more than 55 seconds, all buttons will lock out until pour cancel is released.