

SMART, BOLD, DIGITAL VENDING

QUICK START GUIDE

WELCOME!

Welcome to Cypress Vending's Nibly Snacks program and welcome to the team!

This quick start guide has been designed to help you in the initial setup of your equipment. Please read this guide completely before you start your operations. This will save you time and get your machines up and running smoothly.

A much more complete manual is available online at:

https://www.nibly.ca/ops-manual

We strongly encourage you to refer to the online manual for details regarding wireless payment, your user/software interface, suggested products and suggested suppliers and detailed information about your vending machines.

Please contact us if you would like a hard copy of the complete manual and we will be happy to print one and send it to you. Keep in mind the online manual is updated frequently and should be your primary source for information whenever possible.

Important Contact Information

If you require assistance with your business or your machines, please follow the steps below. Most of the issues that you will encounter have been documented, either in this manual or on the distributor website.

Please be sure to follow this chain of action as questions arise:

1. ALWAYS CHECK THE MANUAL FIRST

Be sure to check the Machine Manual in the Operations Manual for all machine issues.

2. NEXT CHECK THE DEALER WEBSITE

Download the most up-to-date manual and check it.

Check the frequently asked questions section.

3. CONTACT US BY EMAIL: support@cypressvending.ca

Start with your machine's serial number and include as many details about your question or concern as you can. Photos help. We will respond as quickly as possible.

4. CONTACT US BY PHONE: 604-638-6078*

*We can respond to email inquiries much more quickly than phone inquiries, quite often sending you a file or answer to your question right away.

We are almost ready to begin your new business venture!

Before we begin please follow the QUICK START guide to make sure you have covered all the important steps:

PART 1 — BEFORE YOUR EQUIPMENT ARRIVES

1. You have decided on your business structure	☐ Done
2. You have ordered your business cards	☐ Done
3. You have familiarized yourself with key suppliers	☐ Done
4. Your initial product order is planned and ready to be placed	☐ Done
5. You have prepared your investment balance	☐ Done
6. You have decided on your initial product pricing	☐ Done

PART 2 — AFTER YOUR EQUIPMENT ARRIVES

1. Make delivery arrangements	☐ Done
2. Moving and delivery of your machines	☐ Done
3. Storage of your machines	☐ Done
4. Unpacking your machines	☐ Done
5. Tools for initial start-up	☐ Done
6. Locate keys and open door	☐ Done
7. Open your Nibly Snacks vending machine	☐ Done
8. Remove tray lock bar	☐ Done
9. Attach air diverter	☐ Done
10. Retrieve power cord	☐ Done
11. Payment device installation	☐ Done
12. Load product	☐ Done
13. Power up and turn on machine	☐ Done
14. Test machine	☐ Done
15. Refer to **SECTIONS 3 and 4** of the online manual to begin using your Nibly Snacks machine.	☐ Done

PART 1. QUICK START GUIDE

Before your equipment arrives.

DONE

1 DECIDE ON YOUR BUSINESS STRUCTURE

Prior to beginning, you should decide on how you want to structure your new business. Depending on your situation you may decide to run your Nibly Snacks business as:

Proprietorship • Limited Company • Partnership • Subsidiary Company


As every Nibly Snacks operator has different financial needs and goals it is best that you discuss the various options with your accountant before you decide on your business structure.

DONE

2. ORDER YOUR BUSINESS CARDS

Now it's time to order your business cards. These cards will allow you to advertise your business and promote your services to new accounts. You will receive an email from the Cypress Vending team with ordering instructions.

cypressvending.ourproshop.ca



DONE

3. REGISTER WITH KEY SUPPLIERS

In the Suppliers section of the manual (Section 6), you will find the supplier registration forms. Take the time to carefully fill out all necessary forms and make sure to request a catalogue or digital pdf from each supplier!

COSTCO WHOLESALE

VP Vending Products of Canada

wholesale club everything foodservice

Purity Life Purity Life Health Products LP

Dan-D pak

PART 1. QUICK START GUIDE
Before your equipment arrives.

DONE

4. PLAN YOUR INITIAL ORDER

What products do I start with? This is a common question asked by Nibly Snacks operators. We have provided a startup grid in this manual to give you a place to build from.

Once your business is underway, you will then adjust your menu according to the feedback provided by your customers.

Note: Plan your startup grid well before you place your first machine on location.

The grid is laid out exactly like the machine, showing the different selections, products dispensed from these sections and the specific quantities each selection will hold.

For example, if you are purchasing Popcorn for Coil 12, you will need 5 pieces for that coil. To determine the total inventory you need to take the number of pieces required for each selection and multiply by the number of machines that you have.

Example: Selection 12 - 5pcs Farm to Table Popcorn X 10 Machines = 50 Pieces Required.

Now go through each selection and calculate how many pieces you need to fill all your machines. Record this information. The next step is to go to your chosen suppliers and determine exactly what you will need to purchase to fill all your machines. We recommend that you order enough inventory to restock your machines a second time so you are prepared for refilling your machines. You will need to factor in each supplier's minimum order quantity and case sizes to order efficiently.

DONE

5. PREPARE YOUR INVESTMENT BALANCE

Your deposit confirmed your position in the Nibly Snacks program. Your equipment is currently in production or is being shipped to our warehouse. We will be sending you notification once the equipment is on our loading bay and ready to ship. Please make arrangements for your investment balance to avoid any start-up delays.

DONE

6. DECIDE ON YOUR INITIAL PRICING

How much do I charge? We often have operators ask us what they should be charging at their locations. Unfortunately, we cannot give you prices because this is your business. You set the prices that you charge!

We can however give you a rule of thumb that is common in the vending industry. If you buy a product for $1.50 most vendors would charge $3.00 so they would be making a gross profit of $1.50 per bottle. Some products you will get a larger markup. One example is water that is usually purchased for around 20 cents per bottle. Many operators will sell bottled water for $1.50 per bottle, which is over 500% markup.

Some other factors that will go into pricing at your accounts are:

- The commission (rent) paid at the location.
- The type of location (school-aged children's activities may require more affordable products.)

PART 2. QUICK START GUIDE

When your equipment arrives.

DONE

1. MAKE DELIVERY ARRANGEMENTS

Your Nibly Snacks representative will contact you to let you know that your shipment is ready to ship to you. When your equipment has arrived at the local freight terminal you will receive a phone call to notify you. At this point you will have let your Nibly Snacks rep know if you'd like your equipment delivered to your residence or a local temporary storage facility where it can be staged for final delivery to your locations. Please let your Nibly Snacks rep know if you require assistance in locating a local delivery company or secure storage facility for short-term staging. Having your equipment staged and ready to be delivered as soon as you receive location confirmation is the most efficient arrangement. Once a location agrees to host an Nibly Snacks machine, it is best to deliver it immediately.

Note: After initial inspection, replace the cardboard carton until your Nibly Snacks machine is safely in your location clear of all doorways and obstacles. This will prevent damage!

IMPORTANT! BEFORE SIGNING FOR YOUR MACHINES!

You must confirm that all boxes and pieces are with your shipment. You must confirm that NO damage has occurred during shipping. Damage or missing items must be claimed within 24 hours of receipt of shipping. Cypress Vending Corp or the shipping company will not be responsible for damage which is not reported within 24 hours.

DONE

2. MOVING YOUR NIBLY SNACKS MACHINES

Your Nibly Snacks vending machines are large, heavy machines that should be moved by experienced appliance movers. We do not recommend that operators move their own machines in their personal vehicles. It is best to leave this to a professional to avoid any unwanted damage to the equipment or, worse yet, injury due to moving the machine yourself.

BE SAFE—HIRE A PRO!

Your mover should be experienced at moving large, delicate items (pianos, refrigerators, freezers and industrial equipment). They will need a truck with a tailgate lift to receive the machine from the loading bay and to lower the machine to street level. Once on level ground the best way to move the equipment is with a narrow-fork pallet jack (pump jack) with forks of 20 inches in width.

PART 2. QUICK START GUIDE
When your equipment arrives.

DONE

2. MOVING YOUR NIBLY SNACKS MACHINES (CONT'D)

A standard-fork pallet jack will also work with one fork going under the machine and the other fork resting against the front bottom ledge of the machine. It is advised to lift the machine just high enough off the ground to move it. Lower the machine gently when in its final position.

Exercise caution when sliding the machine on polished floor surfaces as it might scuff!

Use caution when moving the machine in a location. It is the operator's responsibility to make sure the move goes off without damage.

DONE

3. STORING YOUR NIBLY SNACKS MACHINES

Your machines can be stored in a dry and secure storage facility. It is advised to store the machines at room temperature. Never tilt or lay your Nibly Snacks vending machine on its side as this will affect the refrigerant gas in the machine's chilling system!

WARNING: NEVER place your Nibly Snacks on it side. If the machine has been tipped more than 30 degrees **DO NOT PLUG IN TO POWER FOR A FULL 24 HOURS.** Doing so will void your machines warranty.

DONE

4. UNPACKING YOUR NIBLY SNACKS MACHINES



Once your machine is stored, you may decide to unpack and test one machine. We recommend that you keep machine's packed and on their pallets until installation ensuring they are fully protected during transportation. If you opt to unpack and test one unit, first, remove the cardboard carton from the machine. If you have enough ceiling height in your storage facility you can simply and carefully pull the cardboard carton off. Be careful not to grab or tear the vinyl display graphics when you pull the box off the machine. The other option is to cut the box and remove it from around the machine. Your Nibly Snacks vending machines have been clearly marked "FRONT". Do not cut on the front or sides of machine but carefully cut the shipping carton on the back. Use a blade that is exposed just enough to cut the cardboard only, carefully cut the box from top to bottom. Do not press hard – remember you are just cutting the cardboard! Next, remove the plastic protection bag from the machine by pulling up. Now you can see your new Nibly Snacks machine. Let's now begin to prepare this machine for operation. **Note: see the "Removing Nibly Snacks Vending Machine from Pallet" supplementary document for more unpacking details.**

PART 2. QUICK START GUIDE

When your equipment arrives.

DONE

5. INITIAL NIBLY SNACKS MACHINE START-UP PROCEDURE

Now that we have our Nibly Snacks vending machine in our location we need to get the new machine ready for customer use! Let's do this in a step- by-step manner:

Tools and items required:

- ☐ 1. Phillips screwdriver
- ☐ 2. Utility knife
- ☐ 3. Scissors
- ☐ 4. Carpet or cardboard to slide machine
- ☐ 5. Complete product for machine
- ☐ 6. Grounded extension cord
- ☐ 7. Drill
- ☐ 8. Small step ladder

PART 2. QUICK START GUIDE

When your equipment arrives.



DONE

6. LOCATE KEYS AND OPEN MACHINE DOOR


Your machines keys are located in the product delivery tray.


This would be a good time to record the machine's location on the key chain to avoid confusion later about which machine belongs to which keys. We have seen this happen many times!

Keep one key on your master key ring for each location. Mark the location name on each key. Keep your spare keys in a safe place in case you ever should lose your keys. It is not fun when you lose all your keys and have no spares!

DONE

7. OPEN YOUR NIBLY SNACKS MACHINE






Place the key in the lock on the front left of the machine. Turn the key counter clockwise and then pull the latch out, then turn the latch counter clockwise several times. Now pull the door open. You will now be able to access the product compartment.

Inside the product compartment, you will find the hardware and accessories for your machine. Remove them from the door and put them in a safe location until you are ready to assemble your machine.

****The machine may be difficult to open if not levelled. A spirit level from the dollar store will assist with that easily.**



DONE

8. REMOVE THE TRAY LOCK BAR

Your machine's vend trays have been secured with a tray lock bar on the right side to prevent them from moving during transportation. You will need to remove the lock bar. Pull upwards on the bar toward the top of the machine and then pull the bar straight out towards you. Store the bar somewhere safe in case you need to move the machine later.

Note: see the "Removing Nibly Snacks Vending Machine from Pallet" supplementary document for more unpacking details.

PART 2. QUICK START GUIDE

When your equipment arrives.

DONE

9. ATTACH AIR DIVERTER

An air diverter comes with your machine. This is a necessary item. It keeps space between your Nibly Snacks vending machine and the wall so your machine's refrigeration system can ventilate properly.

Failure to install the air diverter could result in damage to the refrigeration system which would not be covered by the equipment warranty. To avoid any damage during moving, we recommend installing the air diverter once the machine is placed in its final location.

DONE

10. RETRIEVE POWER CORD

Your power cord has been safely stowed in a rear compartment of your machine to prevent damage during transport. Open stowage compartment by removing the 2 screws at the back of the machine right side.



A. Open stowage compartment by removing the 2 screws at the back of the machine right side.



B. Remove cover plate by rocking it forward.



C. Pull out the power cord and pull it through the slot. Slide plastic cover plate on to the cover plate. Tighten screws.

PART 2. QUICK START GUIDE

When your equipment arrives.

DONE

11. STREAMPAY CARD READER AND COVER PLATE INSTALLATION

Your Nibly vending machine is equipped to handle all forms of electronic payment. Your machine will come supplied with a card reader. Your machine panel has 2 “knockouts” to facilitate the installation of either the card reader. Here is how install the card reader on your configuration. If you wish to add other payment options now or in the future contact your Nibly Vending Representative.

DONE

12 INSTALL STREAMPAY CARD READER SYSTEM

Each machine will come with a StreamPay Card reader. The unit comes in 2 parts; the front bezel called a card reader which your customers will use and the telemetry unit which is installed inside your machine.

a. Install the reader onto the bezel.





b. Install the reader in the device opening using the screws mounted in the frame.







DONE

12. INSTALL PAYMENT CARD READER SYSTEM, CONTINUED


c. First item to plug into the Telemetry Unit is the USB cable. This is very important. Especially with an increase in units being prepped and tested at storage units with battery packs. If you use a battery pack it is essential to plug in the USB Cord first before connecting any other cables into the Telemetry Unit. We suggest doing the USB cable in this order regardless.

The USB cable can plug into any open USB connector on the Silkron IPC (blue box) into a 'USB' slot. Then plug the USB cable into Telemetry Unit (silver box) into USB Connector.






d. Connect the USB-C cable and Silkron MDB adapter Y cable to the reader unit.




e. Plug in the Silkron MDB adapter Y cable and the USB-C Cable into the Telemetry Unit.



DONE

12. INSTALL PAYMENT CARD READER SYSTEM, CONTINUED

f. Install the antenna on top of the door. Thread the cable inside the machine through hole in top of door. Then plug in Antenna into Telemetry Unit.







g. The Telemetry Unit will install on the open space in the instrument panel below the card reader on inside of the door. Keep cables clear of the edge of the door to avoid damage.

h. Once your StreamPay system has been installed, record the Telemetry Unit and card reader serial numbers for each machine and register and submit these numbers with StreamPay (see the StreamPay section of the manual). Registration is necessary to accept cashless transactions.

PART 2. QUICK START GUIDE

When your equipment arrives.

DONE

13. LOAD PRODUCT

Before your installation, you will have recorded your pricing for each item and you will know exactly where each item is to be placed according to your Nibly Snacks Start-Up Grid. Let's begin by doing one tray at a time.

Start with the 1st tray (chip bags)

Pull your 1st product tray out until it tilts forward, allowing you access to the product coils. Inspect the vend coils and make sure none of them have come out during shipping. Starting at the back in the selection 10, begin placing products inside each coil and work your way from back to front. Now go on to 11, and then 12, repeating the same process.

Repeat this process on the 2nd tray.

When you get to the 3rd tray, note that there are spacers on some of the right hand selections. Because they have this adjustable spacer bar, narrow product will travel more easily in the coil. Slide this adjuster bar to snuggly fit the product (not too tight!)

Continue on loading from back to front...

The 4th tray is for large bottles (up to 591ml). Caution – Do not pull this tray out too far forward when filling as bottles and cans of liquids are very heavy.

Place the larger bottles on the outside coils in this section. For large diameter bottles, you might find it is best to place them cap down. This is especially true for Vitamin Water bottles, which are very wide. Other bottles sit nicely in the coils. Make sure that you start loading from the back to front.

The 5th tray is for cans and the 6th tray is for small juice bottles and tetra boxes.

Now that we have loaded the machine – let's tell the machine's brain how much each product's price is.

PART 2. QUICK START GUIDE

When your equipment arrives.

DONE

14. LET'S POWER UP AND TURN ON YOUR NIBLY SNACKS MACHINE

You will need to plug your Nibly Snacks vending machine in at your location. It is recommended to use a dedicated 120V grounded outlet.

Note: We said GROUNDED. Do not plug your Nibly Snacks vending machine into an outlet or use extension cord that is not GROUNDED! Your machine is protected against ground faults. It has been designed for **SAFETY**!

Do not cut corners – you need a grounded outlet and/or a grounded extension cord!

Once you have plugged your machine into the power – we need to turn the machine on. With the control door open you will see the one main power (breaker type switch) at the bottom of the machine in recess below the control panel.

Start by making sure the main power to the machine is in the on position. If this main switch does not turn on – you will need to reset it by pushing the smaller reset tab on the switch. Then turn the switch on again.

PROBLEM?

CHECK THE MAIN POWER FIRST. Make sure that the power receptacle actually has power by plugging in a light, radio, or power tool to ensure there is power at the outlet. If there is no power, talk to your location. If you have power, reset the breaker switch and turn it on again!

With the door shut, you will hear the refrigeration compressor turn on and begin to blow air.

DONE

15. TEST YOUR MACHINE

We will get into more testing of the machine as we begin to program prices and make test vends, but to start, let's make sure the machine's basic functions are working:

1. Is the machine's LCD display on inside the door of the machine?
2. Is the touch screen display on?
3. Is the machine's refrigerated compartment beginning to cool down?

The machine's temperature will start at room temperature and slowly chill down. Watch this temperature over the next 40 minutes to confirm that it is cooling down. Okay, now that we know the machine is functioning correctly let's begin our basic setup.

PART 2. QUICK START GUIDE

When your equipment arrives.

DONE

16. CONGRATULATIONS ON COMPLETING YOUR INITIAL SETUP!

Please refer to Section 3 of the online manual, Vendron/Silkron resources, to begin using the machines user and customer interface:

https://www.nibly.ca/ops-manual

