i⊳clicker **INSTRUCTIONS**

POWER

Solid blue light = Your i>clicker is on.

VOTE STATUS Green = Vote received and confirmed. Red flashing = Vote not received or your instructor has not begun polling; please try again.

LOW BATTERY

A flashing red light indicates that less than 10 hours of battery power remain. Press key in slot on back of your remote to release battery cover and replace 3 AAA batteries. Your remote will shut off automatically after 90 minutes.

REGISTRATION

Your unique remote ID is located on the sticker below.

CHANGE FREQUENCY

Press and hold ON/OFF button until power light flashes. Enter 2-key frequency code provided by your instructor.

Made in China, Patent Pending NEED HELP? www.iclicker.com

TEXT COLOR: BLACK BACKGROUND COLOR: WHITE


SCALE: 1/1

25.4 mm



NOTE: OUTLINE BORDERS ARE FOR ALIGNMENT/REGISTRATION ONLY AND SHOULD NOT BE PRINTED.

(In designation	gn © ALL RIG	HTS RESERVED	PROPRIETARY USE PURSUANT TO COMPANY INSTRUCTIONS
TITLE: INSTRUCTION LABEL GRAPHICS			SCALE: AS SHOWN
DATE:	SHEET:	REVISION:	ARTMASTER NO.
5/10/06	1 OF 1	2ь	103M31



IC: 6495A-RLR13 FCC ID: T24-RLR13



This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

SCALE: 4/1





Inis device compiles with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accep any interference received, including interference that may reuse underted present and

SCALE: 1/1

25.4 mm



NOTE: OUTLINE BORDERS ARE FOR ALIGNMENT/REGISTRATION ONLY AND SHOULD NOT BE PRINTED.

(Indesign © ALL RIGHTS RESERVED			PROPRIETARY USE PURSUANT TO COMPANY INSTRUCTIONS
TITLE: FCC GRAPHICS			SCALE: AS SHOWN
DATE:	SHEET:	REVISION:	ARTMASTER NO.
5/15/06	1 OF 1	3	103M36