

Procédure VPN IKE2- ZYXEL

Cyrus Dehghan – S3P1

<https://cyrusdehghan60.wixsite.com/cyrusdehghanportefol>



Un VPN (Virtual Private Network) permet de créer un tunnel sécurisé et chiffré entre un utilisateur distant ou un site distant et le réseau local de l'entreprise via Internet. Sur un pare-feu comme le **Zyxel USG FLEX 50**, il sert principalement à sécuriser les connexions des télétravailleurs (VPN client-to-site) ou à relier deux sites entre eux (VPN site-to-site) en protégeant les données contre l'interception, en garantissant la confidentialité des échanges et en permettant un accès distant aux ressources internes (serveurs, NAS, Active Directory...) comme si l'utilisateur était physiquement sur le réseau local.



Étape 1 :

En possession d'une licence VPN on va se rendre sur notre interface web du Router Zykel USG FLEX 50 et cliquer sur la baguette magique, puis sur *Remote Access VPN Setup*. Puis sur IKEv2

The screenshot displays the Zykel USG FLEX 50 web interface. At the top, the 'ZYXEL NETWORKS' logo and 'USG FLEX 50' model name are visible. Below the header, there are two tabs: 'General' and 'VPN'. The 'VPN' tab is selected. On the left side, there is a vertical sidebar with several icons; the 'Magic Wand' icon (a star with a wand) is highlighted with a red box. The main content area is titled 'Quick Setup' and contains three options: 'WAN Interface', 'Remote Access VPN Setup', and 'VPN Setup'. The 'Remote Access VPN Setup' option is highlighted with a red box. Below this, a sub-window titled 'Remote Access VPN Setup - IKEv2 (Zykel SecuExtender or non-SecuExtender)' is open. It prompts the user to 'Select a scenario to start...'. There are two scenarios: 'IKEv2 IPSec Client (Zykel SecuExtender, non-SecuExtender)' and 'L2TP over IPSec Client (iOS, Windows, Android)'. The first scenario is selected, indicated by a checkmark and a red box. Below the text for the selected scenario, there is a diagram showing the network topology: an 'Office' connected to a 'Gateway' (router), which is connected to the 'Internet' cloud, and then to a 'Zykel Client' (laptop). The 'L2TP over IPSec Client' scenario also has a diagram showing an 'Office' connected to a 'Gateway' (router), which is connected to the 'Internet' cloud, and then to a mobile device (phone/tablet).

ZYXEL NETWORKS USG FLEX 50

General VPN

Quick Setup

- WAN Interface**
WAN Quick Setting walks you through the steps of getting your device connected online.
- Remote Access VPN Setup**
For employees working anywhere in the world to securely connect with their company's remote LAN.
- VPN Setup**
For creating secure communications between nodes, VPN Quick Setting provides a simplified process to do that.

Remote Access VPN Setup - IKEv2 (Zykel SecuExtender or non-SecuExtender)

Select a scenario to start...

- IKEv2 IPSec Client (Zykel SecuExtender, non-SecuExtender)** ☒
Use this if you are using the Zykel SecuExtender IPSec VPN client or a computer operating system that supports IPSec VPN with IKEv2 (non-SecuExtender VPN client). You can create a Full Tunnel or Split Tunnel VPN rule with Zykel SecuExtender VPN client. You can only create a Full Tunnel VPN rule with non-SecuExtender VPN client.
☐ Full Tunnel
☐ Split Tunnel
- L2TP over IPSec Client (iOS, Windows, Android)**
Use the L2TP over IPSec Client scenario if the VPN client has a supported mobile device and you want to create a Full Tunnel VPN rule only.

Close Next >

Étape 2 :

On va vérifier qu'il récupère bien l'IP de notre WAN, puis on va renseigner notre DNS. Le premier est celui de notre AD, et le second 8.8.8.8.

Remote Access VPN Setup – IKEv2 (ZyXEL SecuExtender or non-SecuExtender)

1 VPN Configuration

2 User Authentication

3 Summary

VPN Authentication Method
Extensible Authentication Protocol (EAP)

Incoming Interface (1)
Interface: wan 192.168.100.105/255.255.255.0

Domain Name / IPv4

Certificate for VPN Validation
Auto

Local Network (1)
Full Tunnel
Allow Client VPN Traffic Through WAN
Split Tunnel
Network of: lan1 10.3.1.0/255.255.255.248

Close < Back Next >

Remote Access VPN Setup – IKEv2 (ZyXEL SecuExtender or non-SecuExtender)

1 VPN Configuration

2 User Authentication

3 Summary

Client Network (1)

IP Address Pool : 192.168.50.1-192.168.50.250

Custom Defined
Starting IP Address: End IP Address:

First DNS Server : ZyWALL Custom Defined 192.168.10.1

Second DNS Server: 8.8.8.8

Upload Bandwidth Limit
Bandwidth: (1-1048576Kbps)

Close < Back Next >

Etape 3 :

On va rajouter deux users de notre AD dans *Available* puis *Member*.

Remote Access VPN Setup – IKEv2 (ZyXEL SecuExtender or non-SecuExtender)

1 VPN Configuration

2 User Authentication

3 Summary

Allowed Local User (1)
Select user from the available user list and move it to the member list.

Add New User

Available

Member
=== Object ===
toto
tata

Close < Back Next >

On va finaliser cela en cliquant sur Save.

Summary
Review the summary of the VPN rule settings and click Save if they are correct.
Please Run the VPN Configuration by going through SecuExtender IPsec VPN Client menu > Configuration > Get from Server.
Note: You can rerun the wizard, but it will overwrite previous settings.

VPN Rule Name	RemoteAccess_Wiz
VPN Authentication Method	EAP
Certificate CN	192.168.100.105
Incoming Interface	Loading 168.100.105/255.255.255.0
Local Network	Full Tunnel
Client Network IP Address Pool	192.168.50.1 - 192.168.50.250
First DNS Server	192.168.10.1
Second DNS Server	8.8.8.8
Upload Bandwidth Limit	
Bandwidth	
Allowed Local User	toto,tata

Close < Back **Save**

Etape 4 :

On va installer le client SecuExtender du VPN.



Products Solutions Support & Learn Where to Buy

Q Sign in



Material	Version	OS	Language	Release Date	Download	Checksum
Datasheet	4		English	September 28, 2023		
Software	IPSec_SSL_VPN_7.7.50.008(s)	Windows	English	January 23, 2025		

Installation de SecuExtender VPN Client

ZYXEL


VPN CLIENT

Bienvenue dans l'Assistant Installation de SecuExtender VPN Client

L'Assistant Installation va installer SecuExtender VPN Client sur l'ordinateur. Cliquez sur Suivant pour continuer, ou sur Annuler pour quitter l'Assistant Installation.

Précédent **Suivant** Annuler


Une fois sur le panneau de connexion SecuExtender VPN on va accéder au Client, et cliquer sur *Obtenir d'un serveur*.




Etape Finale :

On va authentifier notre VPN IKE V2 avec les informations selon notre réseau et on retourne sur le Panneau des Connexions pour lancer le VPN

(ATTENTION avant cela, vérifier que on est en réseau WAN et non en LAN)



On a plus que vérifier que l'IP donnée est bien celle du VPN.



Félicitations, votre VPN est désormais configuré !