H28(B), H29(C) Radio Receiver Assembly TXM+ TXM-ATX+ ATX-9 (B) 10 **(**B) 5 (C 15 (C) > ,3 (\*2) В \*2) ≥ (\*2) 10 **C** 7 (E TX1+ TX1-TX-H27(C) Multi-Media Interface ECU H25(E) Stereo Component Amplifier Assembly

H3(B), H14(G) Display & Navigation Module Display TXM+ TXM-TX1+ TX1-9 **(**G 10 **G** 1 **(**B) 2 **(**B) (+ ۵ ပ 42 GH1 41 GH1 10 B TX1+ TX1-ပ H15(B) Multi-Media Interface ECU 47 IG1 48 IG1 LG (\*1) 24 **B** I3(B) Parking Assist ECU