
14 GX 460 (Cont. next page) ABS, Brake Assist, Crawl, EBD, Downhill Assist Control, Hill-Start Assist Control, A-TRC, Multi-Terrain Select and VSC 30A ABS NO. 2 10A ECU-B G21 Steering Sensor 16 (A) A7(A), A8(B) Brake Actuator Assembly CANL CANH 1 Ap1 p2 Front Speed Sensor LH p1 Front Speed Sensor RH 1 Sq1 G88 Junction Connector q2 Rear Speed Sensor LH Rear Speed Sensor RH

OVERALL ELECTRICAL WIRING DIAGRAM



GX 460 (EM14K1E)

3

