
REAR FLOOR CROSSMEMBER NO. 3 (ASSY)



With the rear floor pan removed.


Symbol meaning

▲ : Remove Weld Points **REMOVAL**

T: Plug Weld **INSTALLATION**

F43332B

REMOVAL-INSTALLATION



F43332

INSTALLATION POINT

- After welding, apply undercoating to the corresponding parts. (See the paint coating)
 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.