

R R

G6(A), G7(B) Combination Meter Assembly IG2 Auto Cruise Cruise Micro Computer WRNP P/SB S ΕP 17 (A) 15 **(**B) 24 (B) A 5 (A) (*18) 5 (B) (*19) G92(A), G143(B) Junction Connector 12 CG1 6 (*18) 6 (*19) W-B C42(A), C36(B), C100(C)
Engine Oil Pressure
Switch Assembly
(**4)

(**4)

(**4)

(**4)

(**4)


(**4)


(**4) G81(A), G82(B) Junction Connector W-B 10 B W-B G106 Junction Connector

- 3 -


- * 1 : 1GR-FE
- * 2 : 2TR-FE
- * 3 : 1KD-FTV
- * 4 : 5L-E
- *11 : Optitron Meter
- *12 : Except 5L-E
- *14 : Except Optitron Meter
- *15 : 5-Door w/ Fuel Sub Tank
- *16 : 3-Door Metallic Fuel Tank
- *17 : *15, *16 *18 : Before Oct. 2010 Production
- *19 : From Oct. 2010 Production *20 : w/o DPF
- *21 : Except 1KD-FTV w/ DPF


G6(A), G7(B)








G6(A), G7(B) Combination Meter Assembly




















* 9 : 5-Door

*18 : Before Oct. 2010 Production *19 : From Oct. 2010 Production

*22 : For production through approximately Jan. 2011

*23 : For production from approximately Jan. 2011

