ELECTRICAL WIRING DIAGRAM

OVERALL

(Cont. next page)

* 1 : w/ Airbag Cut Off Switch Cylinder Sub-Assembly * 2 : RHD 5-Door * 3 : LHD SRS (w/ Curtain Shield Airbag) * 4 : 5-Door * 5 : 3-Door 2 Buckle Switch Buckle Switch LAND CRUISER / LAND CRUISER PRADO (EM17X0E) t Seat Inner Assembly LH LBE+ RBE+ Q2 Front Seat Outer Belt Assembly RH R2 Front Seat Outer Belt Assembly LH R6 Front Side Airbag Squib Circuit LH Q7 Front Side Airbag Squib Circuit RH Airbag Cut Off Switch Cylinder Sub-Assembly Pretensioner Pretensioner SFL+ SFL-SFR+ SFR-PMC+ PMC-≥ € G1(A), Q1(B), R1(D) Airbag Sensor Assembly RBE+ -- RBE-(*2) LBE+ -- LBE-(*3) E1 D2+ D2-+SR ICR+ ICR-26 **(**A**)** 8 **(**A) 7 **(**A) 4 **(**A**)** 30 **(**A**)** 28 **(**A**)** 29 **(**A**)** 27 (A) 8 **(**B**)** 0 **(**B) BBR+ BBR-1 GF1 3 GA5 2 **(** 4 GA5 1 GA5 2 GA5 BCP_ BCR+ ICR-ICR-W-B (*5) Q29 06 Curtain Shield Airbag Assembly RH Curtain Shield Airbag Assembly RH 1**(**F) +SR +SL -SL A21 Front Airbag Sensor LH A20 Front Airbag Sensor RH z5(E) Driver Side Squib Circuit Front Passenger Side Squib Circuit z6(F) Driver Side ≥ Squib 2nd Step Circuit BCR+ BCR-Side Airbag Sensor Assembly RH

28 LAND CRUISER / LAND CRUISER PRADO

